




**BÖHNKE + PARTNER**  
GMBH STEUERUNGSSYSTEME

# WinMOS<sup>®</sup> 300

## Version 5.1

### User Reference






**BÖHNKE + PARTNER®**  
GMBH STEUERUNGSSYSTEME



## GERMANY

**BÖHNKE + PARTNER**  
GMBH STEUERUNGSSYSTEME  
Industrieweg 13  
51429 Bergisch Gladbach  
PHONE + 49 - 2204 - 9553 - 0  
FAX + 49 - 2204 - 9553 - 555  
info@boehnkepartner.de  
www.boehnkepartner.de  
www.WinMOS.de  
www.CANwizard.de

## WORLDWIDE



## GREAT BRITAIN

**GME Controls Ltd.**  
Hailsham / GREAT BRITAIN  
info@gmecontrols.co.uk  
www.gmecontrols.co.uk



## NETHERLANDS

**WITTUR BV**  
Almere / NETHERLANDS  
info@wittur.nl  
www.wittur.nl



## NORWAY

**HAANES IMPORT AS**  
Oslo / NORGE  
himport@online.no



## P. R. CHINA

**Hangzhou Tongda Control System Ltd.**  
Hangzhou / P. R. China  
tdxuli@163.com

© BÖHNKE + PARTNER  
GMBH STEUERUNGSSYSTEME  
Bergisch Gladbach May 2006  
1<sup>st</sup> Edition 2006

User Reference WinMOS®300 Version 5

May 2006

Authors Jörg Hellmich, Roy Schneider

Translator Angela Behrend

Proof Richard Körber, Jörg Hellmich

Layout Jörg Hellmich

Produces with OpenOffice 2.0

Printing and binding BÖHNKE + PARTNER

This user manual is fully protected by copyright in all its parts. All rights reserved, especially the right to translate, recite, reproduce, store in a retrieval system, or transmit in any form or means, electronic, mechanical, photocopying, recording or otherwise. .

Regardless of the care taken in producing texts, illustrations and programs we accept no legal liability whatsoever for possible mistakes and their consequences.

Names used in this manual, trade names, commodity names etc. can be brands even though they have no marking and as such are subject to legal requirements.

© Microsoft, Windows 2000, Windows XP, Access, Borland, dBase, WinMOS and CANwizard are registered trademarks.

<b>1</b>	<b>Preface.....</b>	<b>7</b>
<b>2</b>	<b>General Facts about WinMOS®300.....</b>	<b>9</b>
	2.1 The WinMOS®300 Story.....	9
	2.2 What is New in WinMOS®300 Version 5.....	10
<b>3</b>	<b>WinMOS®300 Version 5 Set Up.....</b>	<b>13</b>
	3.1 WinMOS®300 Database.....	13
	3.2 WinMOS®300 Diagnosis.....	13
	3.3 WinMOS®300 Monitoring.....	14
	3.4 WinMOS®300 Emergency Call.....	14
	3.5 Circular Call Module.....	14
	3.6 WinMOS®300 Call Acceptance .....	15
	3.7 Statistics Module.....	15
	3.8 Overview Module.....	15
	3.9 Synchronisation Module.....	15
	3.10 Plug Ins.....	16
	3.11 Protocols.....	16
<b>4</b>	<b>Installing WinMOS®300.....</b>	<b>17</b>
	4.1 System Requirements.....	17
	4.2 Installation Process.....	17
	4.3 Following the PC Re-Start .....	18
	4.4 Setting Up the Network.....	18
<b>5</b>	<b>The Database.....</b>	<b>19</b>
	5.1 Open and Process the Lift Database.....	19
	5.1.1 Navigation.....	20
	5.1.2 Records.....	20
	5.2 Lift Data in List Form.....	20
	5.3 Database Back-Up Copy.....	20
<b>6</b>	<b>WinMOS®300 Diagnosis.....</b>	<b>21</b>
	6.1 Field of Application.....	21
	6.2 Setting Up the Connection.....	21
	6.2.1 Connection via USB or the Serial Interface.....	21
	6.2.1.1 Extension.....	21
	6.2.1.2 Selecting a Modem.....	21
	6.2.1.3 Direct Connection PC / Controller with Zero Modem Cable.....	22
	6.2.1.4 ISDN.....	22
	6.2.2 Connection via a TCP/IP Compatible Network.....	23
	6.2.3 Connection to a WinMOS®300 Server .....	23
	6.3 Program Settings.....	23
	6.3.1 Visual Program Settings.....	24

6.3.2	Acoustic Program Settings.....	24
6.3.3	Printing.....	24
6.3.4	Window Actions for Incoming Malfunctions.....	25
<b>6.4</b>	<b>User Rights.....</b>	<b>25</b>
<b>6.5</b>	<b>Connect to Lift.....</b>	<b>25</b>
6.5.1	Set Up Connection.....	25
6.5.2	Malfunction Messages.....	26
<b>6.6</b>	<b>Lift Window.....</b>	<b>26</b>
6.6.1	Call Field.....	26
6.6.2	Data Field.....	27
6.6.3	Message and Malfunction Window.....	28
<b>6.7</b>	<b>Maintenance Stack.....</b>	<b>28</b>
6.7.1	Window Contents.....	28
6.7.2	Controller Settings.....	28
<b>6.8</b>	<b>Lift Attendant Status.....</b>	<b>29</b>
<b>6.9</b>	<b>Remote Operation.....</b>	<b>30</b>
6.9.1	Change Lift Parameter.....	30
6.9.2	Configuration Window.....	31
6.9.3	Group Window.....	31
<b>6.10</b>	<b>Remote Operation with the FDG-03.....</b>	<b>32</b>
6.10.1	Parameterizing the FDG-03.....	32
6.10.2	FDG-03 Inputs and Outputs.....	33
<b>6.11</b>	<b>Recording Events (Logging).....</b>	<b>33</b>
6.11.1	Collecting Controller Data.....	34
6.11.2	Command Line Parameter.....	34
<b>7</b>	<b>WinMOS®300 Monitoring.....</b>	<b>35</b>
<b>7.1</b>	<b>Field of Application.....</b>	<b>35</b>
<b>7.2</b>	<b>Setting Up the Connection.....</b>	<b>35</b>
7.2.1	Connection via a TCP/IP Compatible Network.....	35
7.2.2	Connection to a WinMOS®300 Server .....	35
7.2.3	Connection via the Serial Interface.....	36
7.2.3.1	Extension.....	36
7.2.3.2	Selecting a Modem.....	36
7.2.3.3	Direct Connection PC / Controller with Zero Modem Cable.....	37
7.2.3.4	ISDN.....	37
<b>7.3</b>	<b>Program Settings.....</b>	<b>38</b>
7.3.1	Visual Program Settings.....	38
7.3.2	Acoustic Program Settings.....	38
7.3.3	Printing.....	39
7.3.4	Window Actions for Incoming Malfunctions.....	39
<b>7.4</b>	<b>User Rights.....</b>	<b>39</b>
<b>7.5</b>	<b>Set Up Connection to Lift.....</b>	<b>39</b>
<b>7.6</b>	<b>Monitoring View.....</b>	<b>40</b>
<b>7.7</b>	<b>Diagnosis View.....</b>	<b>40</b>
7.7.1	Call Field.....	40
7.7.2	Data Field.....	41
7.7.3	Messages and Malfunctions.....	42

7.8	<b>Maintenance Stack</b> .....	42
7.8.1	Window Contents.....	42
7.8.2	Controller Settings.....	42
7.9	<b>Lift Attendant Status</b> .....	43
7.10	<b>Remote Operation</b> .....	44
7.11	<b>Change Lift Parameter</b> .....	44
7.11.1	Configuration Window.....	45
<b>8</b>	<b>WinMOS®300 Emergency Call</b> .....	<b>47</b>
8.1	<b>Field of Application</b> .....	47
8.2	<b>Setting Up Hardware</b> .....	47
8.2.1	Emergency Call Devices without Receiver.....	47
8.2.2	Emergency Call Devices with Receiver.....	48
8.3	<b>Presentation of Emergency Calls, Symbols</b> .....	48
8.4	<b>Setting Up Emergency Call Receivers</b> .....	50
8.4.1	Requirements, Program Settings.....	50
8.4.2	Test Call after Taking into Service.....	50
8.5	<b>Further Settings</b> .....	51
8.5.1	Send Automatic Confirmation to Emergency Call Device .....	51
8.5.2	Setting for Accepting Check Up Call.....	51
8.6	<b>Communication Monitoring</b> .....	51
<b>9</b>	<b>WinMOS®300 Circular Call Module</b> .....	<b>53</b>
9.1	<b>Field of Application</b> .....	53
9.2	<b>Installation</b> .....	53
9.3	<b>Settings</b> .....	53
9.4	<b>Setting Up Circular Call</b> .....	53
9.5	<b>Comprehensive Overview</b> .....	54
9.6	<b>Activating the Automatic Circular Call</b> .....	54
9.7	<b>Lift Attendant Status</b> .....	55
9.8	<b>Protocols</b> .....	56
<b>10</b>	<b>WinMOS®300 Call Acceptance</b> .....	<b>57</b>
10.1	<b>Field of Application</b> .....	57
10.2	<b>Installation</b> .....	57
10.3	<b>Setting Up a Controller</b> .....	57
10.3.1	Parametering the Call-Back.....	58
10.3.2	Behaviour in Emergencies.....	58
10.3.3	Parametering the Call-Back.....	58
10.3.4	Behaviour in Emergencies.....	59
10.4	<b>Setting Call-Back Parameter</b> .....	59
10.4.1	Trigger Test Call-Back.....	59
10.4.2	Setting Up a Modem.....	59
10.4.3	Printing.....	60
10.4.3.1	SMS.....	60
10.4.3.2	Email.....	60

10.4.3.3	Web Services.....	61
10.4.4	Night Control.....	61
10.4.5	Archiving.....	61
<b>10.5</b>	<b>Using Call Acceptance.....</b>	<b>61</b>
<b>11</b>	<b>WinMOS®300 Statistic Module.....</b>	<b>63</b>
11.1	Field of Application.....	63
11.2	Legends and Navigation .....	63
11.3	Image Presentation.....	63
11.3.1	Trips, Stops and Waiting Times.....	64
11.3.2	Door Movements.....	66
11.3.3	Further Time-Dependent Values.....	66
11.3.4	Further Location-Dependent Values.....	68
<b>12</b>	<b>WinMOS®300 Overview Module.....</b>	<b>69</b>
12.1	Field of Application.....	69
12.2	Installation.....	69
12.2.1	Add Lift Symbol.....	69
12.2.2	Add Detailed Plan.....	70
12.3	Visualisation and Navigation.....	70
<b>13</b>	<b>Installation Examples.....</b>	<b>73</b>
13.1	Service Centre with WinMOS®300 Diagnosis .....	73
13.2	Service Centre with WinMOS®300 Emergency Call .....	74
13.3	WinMOS®300 Monitoring in the Intranet.....	75
13.4	WinMOS®300 Monitoring Direct Serial and Emergency Call.....	76
13.5	WinMOS®300 Monitoring with VPN.....	77
13.5.1	Principle of the dialup into a monitoring-net.....	77
13.5.2	Server setup.....	78
13.5.3	Client setup.....	86
<b>14</b>	<b>Concluding Remarks.....</b>	<b>93</b>
14.1	Important Tips and Remarks.....	93
14.2	Webpage.....	94

# 1 Preface

For everyone with an eye to investing in the future. Whether you are faced with the question of costs or aging technology, remote data transmission in lift technology is a must.

Clever minds are, today, seeking long-term perspectives and not just momentary success. This new technology should exploit the state-of-the-art communication facilities, thus enhancing user-friendliness and safety as well as meeting the following requirements:

## **From time-oriented maintenance to needs-oriented maintenance**

The WinMOS®300 system is a program package for monitoring and diagnosing lift systems. It is part of a control concept developed and produced by BÖHNKE + PARTNER® GmbH.

The system realises the most important aims in remote monitoring:

- ▶ Malfunctions are registered in the supervision centre.
- ▶ Elimination of the faults before operation is disturbed.
- ▶ The needs-oriented maintenance enables longer periods between routine inspections.
- ▶ Operation- and control monitoring is fully automatic on site.
- ▶ Zero fault status targeted.

This powerful tool enables maintenance optimisation and increases lift availability.

BÖHNKE + PARTNER® GMBH STEUERUNGSSYSTEME

Bergisch Gladbach 2006

[Info@WinMOS.de](mailto:Info@WinMOS.de)

[www.WinMOS.de](http://www.WinMOS.de)



## 2 General Facts about WinMOS®300

### 2.1 The WinMOS®300 Story

#### DFÜ300

BÖHNKE+PARTNER introduced their remote diagnostic concept as early as 1992. The DFÜ300 program, a DOS program, had a graphic user surface even at that time.

The following functions could be carried out after establishing a connection:

- ▶ Current message and fault retrieval,
- ▶ Pop stack, view, printout, delete,
- ▶ Fault list, view, printout, delete,
- ▶ Trip number, operating hours retrieval,
- ▶ Car position, car movement tracking,
- ▶ View current call distribution,
- ▶ Enter additional calls.

The modern telegram structure was designed with such foresight that it could be adapted to increasing demands up to the present day, making it possible to manage controllers made in 1992 with any WinMOS®300 version.

#### WinMOS®300


The spread of Microsoft® Windows® as an operating system led to the development of WinMOS®300. At first this was a 16 bit application based on the Borland® OWL, which was later succeeded by the 32 bit version.

WinMOS®300 enabled remote diagnosis and call acceptance of malfunctions and maintenance messages.

#### WinMOS®300 Version 4.0


The increasing demand for a customised remote diagnostic system led to the development of WinMOS®300 version 4.0 which is a completely new development based on MFC from Microsoft®.

WinMOS®300 version 4.0 was designed on a modular basis. The implementation of various perfectly matched modules enabled WinMOS®300 version 4.0 to adapt easily to the respective requirements. So, WinMOS®300 Diagnosis version 4.0 served to equip service centres which received fault messages, maintenance calls and lift attendant messages; WinMOS®300 Monitoring version 4.0 was for real-time monitoring of lifts in closed building complexes. Both versions could be extended with modules for circular-calls, the layout plan, the connection to the emergency centres, the automatic alignment between various centres or statistic evaluation.




▲ Image 1

DFÜ300 with graphic surface in 1992.



▲ Image 2

WinMOS®300 in version 3.x



▲ Image 3

WinMOS®300 Monitoring in version 4.0 enabled real time display of lifts.




## WinMOS®300 Version 5

To be armed for future tasks the old database which ran on dBase IV had to be replaced by a more efficient system. WinMOS®300 version 5 utilises the Microsoft® Access® database.

## 2.2 What is New in WinMOS®300 Version 5

### For those in a hurry – a brief overview:

- ▶ WinMOS®300 structuring,
- ▶ Database,
- ▶ Independent emergency call applications,
- ▶ Design,
- ▶ Language choice,
- ▶ Synchronisation module,
- ▶ Group window in diagnosis,
- ▶ Integration of web cams,
- ▶ Registration,
- ▶ CANopen telegrams,
- ▶ Plug-in technology,
- ▶ Uniform call acceptance in Diagnosis and Monitoring,
- ▶ Extended web services,
- ▶ Connection to an internet portal,
- ▶ Connection to a WinMOS®300 pocket panel,
- ▶ Additional languages French, Dutch and Polish,
- ▶ Massive extension of statistic functions,
- ▶ Creation of load profile via the statistic module and dynamic adjustment of parking floors,
- ▶ Transmission of control cabinet temperature and rope slip,
- ▶ Automatic database back-up,
- ▶ Database export functions,
- ▶ Active screen saver.



**Image 4**

The new WinMOS®300 Start-Centre.

## Detailed description of the new features

The initial start-up with the new WinMOS®300 version shows a lot has changed optically. The layout has been completely overhauled and adapted to Windows® XP specifications.

Structuring is now more defined. Based on the new Microsoft® Access®, the WinMOS®300 Database was relocated and now runs independently with your administration. The new database was equipped with highly efficient import filters and many new columns e.g. for the emergency call alarm plan. The WinMOS®300 applications, Diagnosis, Monitoring and Emergency Call are built up on the database. These can be further extended in performance with the Overview, Statistic, Circular Call and Synchronisation modules. The database can now be automatically backed up in cycle. The new version also comprises a comprehensive export function for all data sets.

Plug ins enable linking to outside databases.

WinMOS®300 Diagnosis sees the return of the group overview as in version 3.x. Up to now the language in which WinMOS®300 appeared depended on the language installed on the PC. The new version allows language changes while running.

The Forwarding module for aligning various WinMOS®300 centres is now called Synchronisation module.

WinMOS®300 Diagnosis and Monitoring professional, can now show internet addresses (URLs) of web cams e.g. for a look into the car following an emergency call.

The registration functions have been extended enabling not only an automatic registration via the net, but also manual registration in case no internet connection is available.

Still available are extended services via the internet e.g. connecting to an internet portal to show lift status on the internet.

Synchronisation of WinMOS®300 centres is no longer confined to modem operation, it is now possible via intranet and internet.

Another important new feature is the software preparation for the integration of CANopen telegrams, making it possible to integrate other lift brands working with the CANopen standard, without additional hardware.

Monitoring centres which ran WinMOS®300 24 hours a day were not in a position to use screen savers as incoming malfunctions had to be recognised immediately. The standard Windows® screen saver does not support this. WinMOS®300 is now equipped with an own active screen saver which prevents this burn-in effect but signals incoming fault messages.



▲ Image 5

Integration of lifts based on CAN-open also possible.



▲ Image 6

An active screen saver signals malfunctions using various symbols.



▲ Image 7

A fault is also signalled when the screen saver is active.

Many, many innovations which justify implementing WinMOS®300 version 5 to optimise your maintenance.  
For the latest information on WinMOS®300 visit [www.WinMOS.de](http://www.WinMOS.de).



▲ Image 8

For the latest information on WinMOS®300 visit our homepage at [www.WinMOS.de](http://www.WinMOS.de).

## 3 WinMOS®300 Version 5 Set Up

WinMOS®300 was designed in a modular way to enable optimal implementation for various usage sites.

### 3.1 WinMOS®300 Database

Based on the new Microsoft® Access®, the WinMOS®300 Database was relocated and now runs independently with its administration. The new database was equipped with highly efficient import filters to import the old databases of versions 3.X and 4.X. The importing of this data is one-time and only necessary when upgrading from an older version.

The WinMOS®300 applications Diagnosis, Monitoring and Emergency Call build up on this database. All WinMOS®300 applications share the same data basis. As it implements the Microsoft® standard format you can easily evaluate the database using the familiar tools from the Office products.


Plug ins enable linking to external databases.

→ see 5.0

### 3.2 WinMOS®300 Diagnosis


WinMOS®300 Diagnosis serves to remotely diagnose or configure a lift system or lift group. It is mainly used in service centres to conduct pre-checks in the case of maintenance or malfunctions making it possible to either identify or rectify them in advance. If an on-site repair is necessary spare parts can be organised in advance.

→ see 6.0



▲ Image 9

WinMOS®300 Database is now an independent module.



▲ Image 10

WinMOS®300 Diagnosis version 5 now also supports integration of web cams.

### 3.3 WinMOS®300 Monitoring




**Image 11**

WinMOS®300 Monitoring in version 5.

The usage of WinMOS®300 Monitoring permits the simultaneous display of up to 32 lift in real time. If WinMOS®300 Monitoring is used as part of a network, up to 128 lifts can be monitored. In addition, it is possible to link various WinMOS®300 work stations via a network. As a dedicated is required to the lifts WinMOS®300 Monitoring is mainly used in self-contained building complexes or on board ships.

→ see 7.0

### 3.4 WinMOS®300 Emergency Call



**Image 12**


WinMOS®300 Emergency Call is now an independent application.

WinMOS®300 Emergency Call was created from the need for a common, centralised administration of emergency calls and malfunctions displayed on a common surface. WinMOS®300 Emergency Call supports devices from different manufacturers. Emergency call input can be recorded in external databases e.g. on the internet.

In most cases it is used together with the Overview module.

→ see 8.0

### 3.5 Circular Call Module



**Image 13**

The Circular Call module carries out cyclical calls from the centre.

The Circular Call module enables one central unit to send a cyclical call to all controllers. Various controller data is automatically received, actions are carried out and recorded in the appropriate protocols.

The circular call module is mainly used in the lift control centre.

→ see 9.0

### 3.6 WinMOS®300 Call Acceptance

Call Acceptance is an integral part of the full version of WinMOS®300 Diagnosis and Monitoring. It takes fault-, message- and maintenance call-backs sent to WinMOS®300 centre by the lifts. In-going call-backs can be forwarded via text messaging or email or they can be recorded in external databases e.g. on the internet. In this way you can observe lift status on the internet.

Call Acceptance is mainly used in the lift service centre.

→ see 10.0

### 3.7 Statistics Module

The Statistics module is an extension of WinMOS®300 Monitoring, it enables statistical evaluation and graphic display of individual lifts. Furthermore, availability of lifts can be determined as well as dynamic adjustment of parking floors according to the statistically determined capacity profile.

→ see 11.0

### 3.8 Overview Module


The Overview module – formerly ZLT module – is an extension of WinMOS®300 which displays the lift status of all systems connected, on one ground plan.

The Overview module is mainly used in the lift company's service centre or in the technical centre of self-contained building complexes.

→ see 12.0


### 3.9 Synchronisation Module

The Synchronisation module enables automatic adjustment of several WinMOS®300 centres via modem connection.




▲ Image 14

Call Acceptance has been extended in a number of ways. It is now also an integral part of WinMOS®300 Monitoring.



▲ Image 15

The new Statistics module in version 5



▲ Image 16

The Overview modules features a convenient zoom function.

### **3.10 Plug Ins**

Connection of alien databases is possible via plug ins. For example, malfunctions monitored by another system are transferred to Call Acceptance and are then available to WinMOS®300 modules.

Moreover, transferring messages from WinMOS®300 to other databases is possible e.g. to connect to SAP systems.

### **3.11 Protocols**

The protocol set-up used has been constantly extended since 1991. So far, few outside companies have decided to integrate WinMOS®300 telegrams into their controllers. On agreement of CAN-open as a standard in the lift industry it will be possible to monitor all controllers which support this standard with WinMOS®300.

# 4 Installing WinMOS®300



Before you can work with WinMOS®300 for the first time you must install it on your PC. The following installation instructions apply to all WinMOS®300 modules.

## 4.1 System Requirements

WinMOS®300 requires at minimum a current PC with:

- ▶ 1 GHz System,
- ▶ 128 MB RAM,
- ▶ Monitor with resolution of 1024 x 768,
- ▶ Microsoft® Windows® 2000 or XP.

For controller connection you require an analogue modem with AT-instruction set as per V.250, an ISDN card resp. a network card. For a direct serial connection of up to 32 controllers an appropriate active interface card is required. WinMOS®300 Emergency Call requires an ISDN card which fully supports the TAPI 2.0 standard resp. a receiver for emergency call devices.


## 4.2 Installation Process

For installation, end all programs currently running. After inserting the CDROM the installation process starts automatically. If the automatic start is deactivated on your PC then type in: START → RUN → X:\SETUP.EXE. X stands for the drive letter of your CDROM drive. Click on Install WinMOS®300 version 5 to start the process. The old version is saved before transmission of the new data.

The button RESTORE OLD VERSION enables de-installation of the new version and restoring of the old version.

Following acceptance of the licence agreement the next dialogue allows you to determine a target directory for WinMOS®300 on your hard disk or in the network.

After successful installation, WinMOS®300 welcomes you. Click CONTINUE and the search for previously installed components or older versions of WinMOS®300 starts. This procedure can take a few seconds. If you have purchased a version with dongle (copy protection) this will now be set up. Finally, re-start your PC.



▲ Image 17  
The set up window for WinMOS®300 version 5



▲ Image 18  
Enter the installation path here.


### 4.3 Following the PC Re-Start

The entry WinMOS®300 is to be found in the start menu and on the desktop. One click and the WinMOS®300 StartCentre appears. Modules not installed are displayed as hatched. A click on this button opens the standard browser and shows information about this module. A click on a non-hatched button starts the appropriate WinMOS®300 program module.


In SETTINGS the user finds a dialogue where the valid settings for all program modules are summarised. Here in COMMON DIRECTORIES you will find the path descriptions which all program modules access.

The directory WINMOS®300 DATABASE is a record of all database tables. In addition it has several sub-directories which record data-set dependent files.

The directory data can be amended if required, e.g. if several work stations should access the same database or the same symbols.



**Image 19**  
Settings and data from older versions are adopted after installation.



**Image 20**  
The new WinMOS®300 Start-Centre.



**Image 21**  
The global settings are made in the settings dialogue.

### 4.4 Setting Up the Network

The WinMOS®300 Database has been network-compatible since version 3.0. The program modules are still executed locally on each work station.

Follow these instructions for network installation:

- ▶ Create a directory WINMOS and the sub-directories WINMOS\DATA, WINMOS\OVERVIEW and WINMOS\ICO on the server drive.
- ▶ Install the program on all workstations. Make sure you use the same program version of WinMOS®300.
- ▶ Inform the locally installed WinMOS®300 about the database directory (WINMOS\DATA), the symbol directory (WINMOS\ICO) and the ZLT-directory (WINMOS\OVERVIEW). Do this by starting WinMOS®300 and clicking on the button SETTINGS.

The dialogue box which appears allows you to inform the workstations about the directories on the server. See the previous chapter INSTALLATION. The settings made here can be protected from unauthorised access by an administrator password.

Each workstation requires the rights to read, write and create directories in the WinMOS directory on the server.

## 5 The Database

Based on the new Microsoft® Access®, the WinMOS®300 Database was relocated and now runs independently with its administration. The new database was equipped with highly efficient import filters to import the old databases of versions 3.X and 4.X. The importing of this data is one-time and only necessary when upgrading from an older version.

The WinMOS®300 applications Diagnosis, Monitoring or Emergency Call build up on this database. All WinMOS®300 applications share the same data basis. As it implements the Microsoft® standard format you can easily evaluate the database using the familiar tools from the Office products. Plug ins enable linking to outside databases.

The button DATABASE in the StartCenter opens the WinMOS®300 Database which offers various administration features.

### 5.1 Open and Process the Lift Database

Clicking this link opens the lift database with all familiar navigation and editing facilities.


For each lift you want to connect to WinMOS®300, create a data sheet here. Enter the following information at minimum.

- ▶ The RD NUMBER as clear identification. The lift is assigned to the data sheet using this number; this makes it imperative that the RD NUMBER in the data sheet and lift controller (basic menu) are identical.
- ▶ Enter the modem telephone number or IP-address of the conservator in the field TELEPHONE NUMBER.
- ▶ EMERGENCY CALL DEVICE and DEVICE ID are required if you administer the emergency calls with WinMOS®300. This data is required to assign incoming calls to the correct lift.
- ▶ STANDARD CONNECTION / DIALLING IN STAGES – This setting is required when the lift's modem shares a line with an emergency call device which supports dialling in stages.

Furthermore, we recommend filling out the following fields:

- ▶ The field NUMBER OF STOPS determines how many floor definitions you may enter in FLOOR DEFINITIONS.
- ▶ Fitter: MOBILE SMS, TELEPHONE, NETWORK and EMAIL – These fields are used by other modules e.g. Call Acceptance, to forward lift related malfunctions per SMS or email.

All other fields are optional.



**Image 22**

The data sheets contain all relevant, and many informal data sets about the lifts.

## 5.1.1 Navigation



**Image 23**

The navigation bar helps you move through the database.



**Image 24**

Safety circuit terminal definitions can be adjusted in the data sheet.

The navigation bar is located in the lower part of the window. By using this bar you can navigate through the database, create new data sheets or delete the current data sheet.


The button COPY has the same function as opening a new data sheet. The only difference is that all entries in the current data sheet are copied to an empty, new sheet which has no RD number. This is a quick and easy way of, for example, entering a group lift into a database.

The button FLOOR DEFINITIONS opens a dialogue box where building related floor definitions can be entered. The number of floors is directly correlated to the number listed in STOPS.

If you are opening a data sheet and the terminal definitions in the safety circuit differ from the set definitions then you can amend these in TERMINAL DEFINITIONS.

## 5.1.2 Records

All fault messages transmitted are recorded in the database. Press the button marked RECORDS and registration cards appear in a dialogue window showing collective data from the pop-stack, fault-messages, maintenance list, attendant status (AWS) and emergency calls.



**Image 25**

All lift records of malfunctions, maintenance, attendant functions and emergency calls are recorded for retrieval.


## 5.2 Lift Data in List Form

The content of the lift database can be displayed as a list in this window. The columns can be sorted and printed out. A double click on a data set effects connection to that lift. The same process is effected if a data set is marked and the user then clicks on DIAL.

## 5.3 Database Back-Up Copy

To prevent data loss we recommend cyclical back-up of the database. Enter the directory in which the back-up should be stored and the time it should be carried out.

If required, one click on the field RESTORE DATABASE FROM BACK-UP restores the data saved.



**Image 26**

Database back-up can be carried out cyclically or manually.

# 6 WinMOS®300 Diagnosis

## 6.1 Field of Application

WinMOS®300 Diagnosis serves to remotely diagnose or configure a lift system or lift group. It is mainly used in service centres to conduct pre-checks in the case of maintenance or malfunctions making it possible to either identify or rectify them in advance. If an on-site repair is necessary spare parts can be organised in advance.



## 6.2 Setting Up the Connection

The first task for the user is to set up the program. Select a connection mode to the the controller. Go to SETTINGS in the FILE MENU.

### 6.2.1 Connection via USB or the Serial Interface

With the USB or serial interface on the computer the PC can connect to the controller via analogue modem, ISDN or direct serial with a zero modem cable or RS422 converter.

Click on the button MODEM/INTERFACE to set up a modem connection. In the dialogue which then appears, select the modem or COM port through which the connection is to be made.



▲ Image 27

Click on the button MODEM/INTERFACE to set up the connection.


#### 6.2.1.1 Extension

If you have to dial an »0« to get a line, activate this option. All of the telephone numbers stored in the database then automatically receive an »0,« when dialled.

#### 6.2.1.2 Selecting a Modem

If your modem is correctly installed in Windows® you can select it by name from the list. Alternatively, mark the serial port (COMx), to which the modem is connected. Each USB modem which is set up on the PC appears by name in the list together with the COM port assigned by Windows®.

If you choose to amend the interface parameter between the PC and the modem just click on the field CHANGE SERIAL PARAMETER. A dialogue window opens allowing you to select whether the modem dials in tone or pulse mode. The tone mode is most widely used. The pulse mode has only been retained for reasons of compatibility with older telephone systems. In EXTENDED, ADDITIONAL AT-COMMANDS you can enter commands which are sent to your modem on initialising. See your




▲ Image 28

In this dialogue, select the COM-port via which the connection should be made.




▲ Image 29

Selecting a modem from the modem list.



**Image 30**

The standard setting for present day telephones systems is tone dialling.



**Image 31**

This window is for setting interface features



modem manual, if required. A common entry in this field is »M0« resp. »M1«, which either mutes or silences the modem speakers.

Click on INTERFACE PARAMETER to amend the setting on the interface to which your modem is connected, should this be required.

### Bits per Second

Set to the maximum transmission rate from modem to PC. If you have correctly installed your modem in Windows® and selected it in the list, this point does not apply. (For a 33600bps modem e.g. a bit rate of 57600bps).

### 6.2.1.3 Direct Connection PC / Controller with Zero Modem Cable

To connect the controller via a zero modem cable in a direct serial mode, connect to a free COM port on your PC; now set the connection setting of this port so it accords to the controller settings. (see controller manual).

### 6.2.1.4 ISDN

To use an ISDN connection you may use an external device or an internal ISDN card. If your computer is equipped with an ISDN card a Fossil driver must be installed. This driver translates the AT-commands to the corresponding ISDN ones. An external ISDN device is approached like its analogue counterpart.

Not every ISDN card supports analogue telephone operation. Check with your specialist before purchasing an ISDN card / ISDN device. There are pure ISDN devices with which you can only connect to ISDN connections. There are also devices which are built for both connections modes (analogue and ISDN). We recommend these for monitoring controllers with analogue and ISDN connections.

## 6.2.2 Connection via a TCP/IP Compatible Network

Today, most controllers are connected via a local network (intranet). For this purpose they are equipped with a comserver and connected to the intranet. The WinMOS®300 PC is also connected to the intranet via its network card. Go to **SETTINGS** and activate the option **NETWORK CONNECTION (TCP/IP) DIRECT TO CONTROLLER**. The IP address of the controller's comserver is entered in the data sheet instead of the telephone number, enabling a connection to the controller.

## 6.2.3 Connection to a WinMOS®300 Server


The connection between a controller and a WinMOS®300 PC is a point-to-point connection. So that other PCs have access to a controller's data, the PC connected to the controller acts as a server making available all lift data to WinMOS®300 clients. To set up a connection to a WinMOS®300 server activate the option **COLLECT DATA FROM ANOTHER WINMOS®300 SERVER** in **SETTINGS**. Enter the IP address or the host name of the WinMOS®300 server in the window **WINMOS300 SERVER SETTINGS**.

## 6.3 Program Settings

To adjust program settings, go to **FILE** menu and then select **PROGRAM SETTINGS**.


The settings are divided into 4 groups which are marked by symbols.

- ▶ Visual program settings,
- ▶ Window actions for ingoing malfunctions and screen savers,
- ▶ Acoustic program settings,
- ▶ Printing.




▲ Image 32

You require a network card to connect a controller via an intranet.



▲ Image 33

The network settings to a WinMOS®300 server.



▲ Image 34

Various program settings can be adapted in this window.

### 6.3.1 Visual Program Settings

**ALIGN CONTROLLER TIME WITH PC TIME** – If this option is active the current time will be transmitted to the controller each time it is connected.

**RE-CALCULATE BUILDING SCALE AT EACH PROGRAM START** – If this option is active the lift shaft display is re-calculated using the absolute value transmitter data at each program start.

Furthermore, you can change the character set used for the pop stack, malfunctions list etc. or you can select a bold font in the dialogue window.

### 6.3.2 Acoustic Program Settings

Mark the fields left of the action to activate an acoustic signal. Enter the sound file to be played, to the right of the action. To simplify choosing the file name you can select a sound file »\*.wav« by clicking on the field marked with three points in the sound selection box.

### 6.3.3 Printing

**PRINT IMMEDIATELY WHEN MALFUNCTIONS INCOMING** – If you have an online connection to a lift and a malfunctions message comes in putting the lift **OUT OF ORDER** a protocol print out is immediately generated. You can determine if a full page is printed or just a line which includes only RD number and lift number. The latter printing method only works with dot-matrix printers (endless paper). Ink-jet and laser printers work with individual pages.



▲ Image 35

If the lift is free from faults the active screen saver shows this.

## 6.3.4 Window Actions for Incoming Malfunctions

This function allows you to set when WinMOS®300 is to appear automatically in the foreground. Furthermore, the active WinMOS®300 screen saver can be activated here. This shows an OK symbol when the lift is connected to WinMOS®300 and there is no current malfunction, and a stop symbol in case of malfunction.

## 6.4 User Rights

To adapt user rights go to FILE menu and select SETTINGS, then choose USER RIGHTS.

Now you can determine which rights each user is assigned within WinMOS®300. The following controller functions can be activated or deactivated:

- ▶ Block floors,
- ▶ Place calls,
- ▶ Remote OFF/ON,
- ▶ Amend lift parameters,
- ▶ Configuration mode,
- ▶ Delete malfunction stack / -list,
- ▶ Change call-back parameter.

Moreover, visualising functions can be set:

- ▶ Malfunctions / messages visible,
- ▶ Call field visible.

## 6.5 Connect to Lift

### 6.5.1 Set Up Connection

There are various ways of connecting to a lift.

- ▶ Go to FILE and then DATABASE.
- ▶ Navigate to the lift required.
- ▶ Click on the DIAL button.

While connecting, a window opens showing which number is being called, the feedback from the modem and the dialling status. After 4 unsuccessful attempts, dialling is aborted. Clicking CANCEL stops the dialling process at any given time.



▲ Image 36

This screen saver symbol signals a malfunction.



▲ Image 37

Click DIAL on the symbol bar and you will be connected to the last lift dialled in the database.

## 6.5.2 Malfunction Messages

If the modem was unable to establish a connection, then it re-dials after 10 seconds. In case of repeated breakdowns in connecting, take the following steps:


- ▶ Check if the modem is connected to the phone line.
- ▶ If the modem is on an extension line, check if there should be a number (e.g. a »0«) to get a line.

If the number you are dialling is busy, WinMOS®300 waits ten seconds before re-dialling.



**Image 38**

While connecting, status and telephone number are displayed.



**Image 39**

This call field allows entry of all calls, blocking and releasing of all floors.

## 6.6 Lift Window

When connecting to a controller the lift window is filled with data sent by the controller. This window displays dynamic controller data in graphic form; the lift shaft, the car position, the safety circuit and other details are in the graphic layout. In addition, you will find all current messages, malfunctions, the pop stack and the list.

The display is divided into 3 parts:

- ▶ On the left is the field which includes all pending calls and blocked floors and the shaft display, which shows the dynamic movement of the car and the doors.
- ▶ In the middle is the database information and the dynamic lift data.
- ▶ On the right, 4 fields display the current messages and malfunctions, the pop stack and the malfunction list. If a web cam is connected it is also shown here when active.

### 6.6.1 Call Field

Following connection, the call field depicts all calls configured in the controller as meaningful symbols

cabin call	no call		call active	
landing call	up		down	
floor	free		blocked	


The shaft display is to scale if the lift has an absolute copy mechanism (AWG, USP, ... ). If it only has a magnetic switch copier then a standard shaft with a defined number of floors is shown. The car movements are also transmitted accordingly to the copy mechanism.

## 6.6.2 Data Field

The display is divided into individual sections which can be selectively hidden or shown.

- ▶ The section **DATABASE** shows the lift data from the data sheet. It contains the lift number, the operator, the manufacturer, the address and the remote data transmission number of the lift.
- ▶ The section **OPERATING DATA** informs of the current time and date, operating hours, number of trips, rope slip, temperature in the control cabinet and the current lift load. Some of this data can only be displayed if the lift is equipped with the appropriate sensors.
- ▶ **LIFT TYPE** – is the section where the basic lift information set in the controller is displayed, such as drive type, processor type, type of doors and the controller. It is pointed out here if the remote data transmission data sheet number does not accord with the lift connected.
- ▶ In the section **SAFETY CIRCUIT AND SIGNALS** the safety circuit terminals and the status of the levelling, impulse- and correction signals are displayed as symbols.
- ▶ The section **STATUS** displays the function of the light grid, the direction arrows, the drive signal and the floor status. Furthermore, the status of the lithium battery on the processor unit is shown.
- ▶ The section **AWG (ABSOLUTE VALUE TRANSMITTER) / USP DATA** shows the current position, the deviation from levelling position and the current car speed if the lift is equipped with an absolute copying mechanism.
- ▶ The section **PRE-CONTROL DOORS** shows the pre-control door signals. If the controller has doors with limit switches then the conditions of the **DOOR LIMIT SWITCH OPEN** and **DOOR LIMIT SWITCH CLOSED** are shown as symbols next to the door motor indicators.
- ▶ In the section **INITIATE ACTIONS** are the buttons for the following actions: **DELETE POP STACK**, **DELETE MALFUNCTION LIST**, **RE-CONNECT** and **CHANGE CALL BACK PARAMETER**.
- ▶ The section **WEB CAMERA** has a button which connects you to the given website of a potential web cam. On activating the check box **EMBEDDED VIEW**, the web site is not depicted in its own window but on the right below the current malfunctions.

All sections can be overlaid via the check box on the right side. Use this option if your screen resolution does not allow display of all section at the same time.



**Image 40**

This data field displays the database information and the dynamic lift data.



**Image 41**

This window shows the current lift messages.




**Image 42**

This window shows the current malfunctions.



**Image 43**

The pop stack shows the malfunctions with time stamp.



**Image 44**

The number of malfunctions in the malfunction list.

## 6.6.3 Message and Malfunction Window

The right side of the lift window displays the information about pop stack, malfunction list, current messages and malfunctions. Malfunctions and messages are only shown as long as they prevail. The windows MALFUNCTION LIST and POP STACK show records of previous malfunctions, this also includes the number of malfunctions resp. their date and time.

## 6.7 Maintenance Stack

To view the maintenance stack select VIEW in the MAINTENANCE STACK menu. A window opens, showing the last maintenance entries from the controller which was called.

### 6.7.1 Window Contents

The individual maintenance information is displayed using various symbols:

- ▶ Maintenance intervals are marked by a red circle.
- ▶ Other maintenance actions are marked by a green circle.

Each entry effects transmission of a personnel code (PKZ). This is used to identify the person who carried out the action. To use this option, activate on the controller. Following activation, a personnel code will be requested for each maintenance action (maintenance on) carried out. Actions carried out on WinMOS®300 are assigned a personnel code in the controller and recorded in the pop stack. This remote data transmission personnel code is transmitted when dialling a controller and is currently fixed with the abbreviation »WMOS«.

### 6.7.2 Controller Settings

When a maintenance interval point e.g. maintenance, operating hours or number of trips is reached, the controller or the remote data transmission device FDG can emit a so-called maintenance call-back. This function must be previously set in the controller. Once set, the maintenance call-back is treated like a malfunction call-back, it is accepted and then recorded in the database.

## 6.8 Lift Attendant Status

To view the controller's lift attendant status go to VIEW and select LIFT ATTENDANT STATUS. The lift attendant status contains the current information which is transmitted from a controller + absolute value transmitter or in case of an alien controller, an electronic lift attendant module.

The lift attendant records can be retrieved via the "records" button. The following information is evaluated by the controller and transmitted to WinMOS®300:


- ▶ Extreme non-levelling in the previous week:  
A second channel (i.e. an additional levelling switch) determines and counts up extreme non-levelling from the controller + lift attendant module (AWM02) / FDG-03.
- ▶ Light barriers OK:  
If there is no change in the light barrier signal for 20 consecutive trips then a malfunction is assumed and an appropriate message is emitted.
- ▶ Light barriers equipped:  
An appropriate abbreviation is entered for each light barrier (A = door A,...) to activate door monitoring.
- ▶ Car light monitoring OK:  
Intelligent sensors in the lift attendant module resp. electronic attendant module analyse the car light electricity. The lift attendant status window shows the condition of the car light with yes/no for car light OK/faulty.
- ▶ Car light monitoring active:  
This entry shows if the car light monitoring feature is activated.
- ▶ Last trip:  
Here you find the date and time of the last proper trip. A proper trip is one where no malfunction occurs.
- ▶ Last emergency call:  
Date and time of the last emergency call (pay attention to the emergency call delay time in the controller's basic menu).
- ▶ Maintenance start:  
Gives the date and time the last maintenance started.
- ▶ Maintenance finish:  
Gives the date and time the last maintenance ended.
- ▶ First proper trip:  
Gives the time and the date of the last proper trip following the last lift malfunction.



Maintenance	Date	Time	F %
Maintenance call	01.12.2004	11:57	00:4
Maintenance start	01.12.2004	11:15	
Maintenance call	23.02.2005	13:23	F82
Maintenance start	23.02.2005	14:01	F82

▲ Image 45


The maintenance stack contains all maintenance information with time stamp.



Lift	"Lift 1"
RD Number	"0000"
Photo/Stack position	"00"
Strand / Day	"Industriezone 13, Barchaus"
AWM02 State of : 24.02.2004 10:22:00	
Extreme non-levelling	14
Light barrier present (A, B, C)	A--
Light barrier status (A, B, C)	A--
Light barrier control active	Yes
Car light ok	Yes
Last date:	14.02.2004 10:22:00
Last emergency call	25.02.2004 11:22:30
Begin last maintenance	25.02.2004 11:46:00
Last maintenance	25.02.2004 12:01:26
Last date after malfunction	

▲ Image 46

The lift attendant status with the current data.



Photo/Stack position	0000	Day	22030
Strand / Day	0000	Day	000000
Photo/Stack position		Day	

▲ Image 47

This window enables entry of various lift parameter.

## 6.9 Remote Operation

Using WinMOS®300 you can make calls online, block floors, change lift controller parameter which are not relevant to safety, switch outputs and show input status.

### 6.9.1 Change Lift Parameter

Go to the **PARAMETER** menu and select **CHANGE LIFT PARAMETER**. Select the parameter group you wish to change from the dialogue box.

The label **GENERAL** encompasses the fundamental parameter; RD number, lift number, basic code, service code, remote data transmission password, trip number, operating hours and date, controller time. The controller's remote data transmission number entered here must comply with the appropriate data sheet in the WinMOS®300 database!

The label **TELEPHONE NUMBERS** offers various fields for entry. The controller uses these numbers for call-backs. If the first number cannot be reached the second number is dialled as long as there is a number entered in field 2. If there is no answer here, then the next number is dialled if a number has been entered in field 3.

The label **MAINTENANCE** allows definitions of various maintenance intervals. When these intervals are reached (e.g. 30000 trips) a message is sent to the central unit and the value is then increased to that of the next cyclical maintenance interval (e.g. 5000 trips). Thus, the controller signals the need for e.g. cyclical maintenance every 5000 trips. Cyclical interval values can be entered for the number of trips, the operating hours and a monthly interval.


The label **SPECIAL FLOORS** allows entry of parking stops, inspection stops, resting stops, fire stop, fire brigade stops, emergency power stops and the maintenance stop.

After setting the parameter the values must be sent to the controller by clicking on **SEND**. The field **CLOSE** closes the window without further storing the parameter in the controller.



**Image 48**

Telephone numbers for malfunctions, emergency calls and emergencies can be set here.



**Image 49**

Set the values for the maintenance intervals in this window.

## 6.9.2 Configuration Window

This window serves to configure the controller via WinMOS®300. It shows the display, the keys if available and the controller bar graph. This means all service menu parameter can be set in the native language on site. The configuration of the converter connected can also be carried out in DCP-mode. Activate it via **PARAMETER → CONFIGURATION VIA THE DISPLAY**.

The display content appears somewhat delayed in modem connections due to the restricted band width. So, please click slowly and wait for the text changes in the display.

DCP-MODE ON/OFF in the display menu can be activated when the controller dialled is equipped with a converter which supports this mode.

The flip switch marked L-Call (Landing Call), effects deactivation of remote data transmission to the landing call control. Deactivation of the landing call control in this option can only be changed via remote data transmission.


## 6.9.3 Group Window

The new version of WinMOS®300 Diagnosis sees the return of the group window as it was in WinMOS®300 version 3.x. After dialling one lift in the group with WinMOS®300 Diagnosis the shafts are displayed with the cabin and landing group calls.



**Image 50**


The configuration window shows the WinMOS®300 service menu.



**Image 51**

The group window displays the shafts in the lift groups in WinMOS®300 Diagnosis.

## 6.10 Remote Operation with the FDG-03



**Image 52**  
The dialogue box for parametering the FDG-03.

The remote data transmission device FDG-03, successor of the FDG-02, is versatile in configuration. Much experience from the FDG-02 was used in developing the FDG-03. For example, the device is equipped with a display which makes on site installation even more convenient. Input voltage for the inputs can be parametered so a hardware adoption is no longer necessary. Furthermore, all modules essential for the function of the electronic lift attendant have been integrated. The scope of function includes freely definable in-/outputs. To assign these terminals names and relate malfunction texts to these WinMOS®300 has a separate dialogue box. This is available on- and offline. Pre-requisite is that the system is set in the data sheet as processor type FDG-03/EAM-01. The FDG-03 does not necessarily have to be connected to a lift. In addition to the lift specific software there is also software which turns the FDG-03 into a universal remote diagnostic device. In this context, the malfunction texts and the user defined graphics fulfil their purpose.

### 6.10.1 Parametering the FDG-03




**Image 53**  
The FDG-03 inputs can be individually parametered.

The dialogue box is divided into several flags:

#### Flag Inputs

The input terminal descriptions are entered in the first (grey hatched) column, as they are found on the device. The terminal descriptions can be amended in the second column which should appear in the dialogue in/output box next to the terminal symbol. The malfunction text, which appears in the pop stack and the malfunction list window can be changed in the third column when the terminal is triggered. Just click on the entry with the left mouse button to change it.



**Image 54**  
The outputs can also be assigned individual identifiers.

#### Flag Outputs

The output terminal descriptions are entered in the first (grey hatched) column, as they are found on the device. The terminal descriptions can be changed in the second column which should appear in the dialogue in/output box next to the terminal symbol. The malfunction text, which appears in the pop stack and the malfunction list window can be changed in the third column when the terminal is triggered. Just click on the entry with the left mouse button to change it.

## Flag Presentation


If the FDG-03 is not used in connection with a lift a graphic file name can be entered here which is then shown as an alternative to the call field. The graphic formats Windows Bitmap (\*.bmp) and Windows Device Independent Bitmap (\*.dib) are supported.

## 6.10.2 FDG-03 Inputs and Outputs

This box can be reached via USER DEFINED IN-/OUTPUT in the VIEW menu.

The left column shows the FDG-03 specific inputs.

The right frame contains the outputs. The outputs can be operated by mouse click.



▲ Image 55

The FDG-03 can also be used to monitor wind power plant or machines.

## 6.11 Recording Events (Logging)

If this function is activated, events and conditions such as PLACE CALLS, SAFETY CIRCUIT INTERRUPTION, lift attendant data etc. is recoded in a plain text file.

In addition, the user can have incoming messages and malfunctions recorded.

Here is an extract from such a record:

Recorder file open: Thursday, February 14, 2002 - 16:30:48

\*\*\*\*\*

14.02.2002-16:30:52 -> Etage/Floor 6, S.Kreis/S.Circuit (9)(15) 16 17 18 19

14.02.2002-16:30:52 -> Bü.auf/Lev.up (\*) -- Bü.ab/Lev.down (\*)

14.02.2002-16:30:52 -> Korr.oben/Corr.top -- Korr.unten/Corr.bottom --

14.02.2002-16:30:52 -> Meldungen/Messages:

transmitter/Geber ok !

Maintenance interval „appointment" reached

Maintenance interval "trips" reached

Maintenance interval "operating hours" reached

14.02.2002-16:30:52 -> Störungen/Malfunctions :

keine/none

14.02.2002-16:30:55 -> Innenruf/Cabincall -A- : 16

14.02.2002-16:30:58 -> Etage/Floor 6, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)

14.02.2002-16:30:59 -> Fahrt auf / Drive up

14.02.2002-16:30:59 -> Bü.auf/Lev.up (\*) -- Bü.ab/Lev.down


14.02.2002-16:30:59 -> Korr.oben/Corr.top -- Korr.unten/Corr.bottom --

14.02.2002-16:31:00 -> Bü.auf/Lev.up -- Bü.ab/Lev.down

14.02.2002-16:31:00 -> Korr.oben/Corr.top -- Korr.unten/Corr.bottom --

14.02.2002-16:31:00 -> Etage/Floor 7, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)

14.02.2002-16:31:01 -> Etage/Floor 8, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)



▲ Image 56

The dialogue box shows the current in- and output signals.




▲ Image 57

WinMOS®300 Diagnosis is able to record all events.

```

14.02.2002-16:31:02 -> Etage/Floor 9, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)
14.02.2002-16:31:04 -> Etage/Floor 10, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)
14.02.2002-16:31:05 -> Etage/Floor 11, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)
14.02.2002-16:31:06 -> Etage/Floor 12, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)
14.02.2002-16:31:08 -> Etage/Floor 13, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)
14.02.2002-16:31:09 -> Etage/Floor 14, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)
14.02.2002-16:31:10 -> Etage/Floor 15, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)
14.02.2002-16:31:12 -> Etage/Floor 16, S.Kreis/S.Circuit (9)(15)(16)(17)(18)(19)
14.02.2002-16:31:15 -> Bü.auf/Lev.up -- Bü.ab/Lev.down (*)
14.02.2002-16:31:15 -> Korr.oben/Corr.top -- Korr.unten/Corr.bottom --
14.02.2002-16:31:15 -> Bü.auf/Lev.up (*) -- Bü.ab/Lev.down (*)
14.02.2002-16:31:15 -> Korr.oben/Corr.top -- Korr.unten/Corr.bottom --
14.02.2002-16:31:16 -> Fahrt/Drive: Stop
14.02.2002-16:31:16 -> Etage/Floor 16, S.Kreis/S.Circuit (9)(15) 16 17 18 19
Recorderfile closed: Thursday, February 14, 2002 - 16:32:16
*****

```



**Image 58**  
The information for recording can be previously defined.


If the file exceeds a size of 20 MB, a back-up is made and a new file with the same name is opened.

### 6.11.1 Collecting Controller Data

This function reads all controller settings and stores them in a text file. Set the controller to basic menu and then activate this function in WinMOS®300. You will find it at PARAMETER → COLLECT CONTROLLER DATA (F7). Now follow the on-screen instructions. As this option only works when the controller is in basic menu, it cannot be effected via modem connection.

### 6.11.2 Command Line Parameter

When WinMOS®300 Diagnosis is supposed to call a certain lift automatically after starting, then you can enter /CALL: followed by the remote data transmission number in the command line. The complete command line would be: c:\WINMOS\DIAGNOSEMODUL.EXE /CALL:5061 in case of the lift with RD number »5061«.



**Image 59**  
Controller data can be stored in a file via this menu item.

# 7 WinMOS®300 Monitoring

## 7.1 Field of Application

WinMOS®300 Monitoring serves to constantly monitor and remote control lifts. It is primarily used in building automation, in service- or technical centres and for gate keeper workstations. As a constant connection to the lifts is maintained when using WinMOS®300 Monitoring, the complexes are usually self-contained buildings or ships which have a network available for the premises automation. WinMOS®300 Monitoring offers the user a clear overview of all lift conditions, convenient operation and extremely efficient statistic functions which leave nothing to be desired.

## 7.2 Setting Up the Connection


The first task for the user is to set up the program. Select a connection mode to the controller. Go to **SETTINGS** in the **FILE** menu.

### 7.2.1 Connection via a TCP/IP Compatible Network


Today, most controllers are connected via a local network (intranet). For this purpose they are equipped with a comserver and connected to the intranet. The WinMOS®300 PC is also connected to the intranet via its network card. Go to **SETTINGS** and activate the option **NETWORK CONNECTION (TCP/IP) DIRECT TO CONTROLLER**. The IP address of the controller's comserver is entered in the data sheet instead of the telephone number, enabling a connection to the controller.

### 7.2.2 Connection to a WinMOS®300 Server


The connection between a controller and a WinMOS®300 PC is a point-to-point connection. So that other PCs have access to a controller's data, the PC connected to the controller acts as a server making available all lift data to WinMOS®300 clients. To set up a connection to a WinMOS®300 server activate the option **COLLECT DATA FROM ANOTHER WINMOS®300 SERVER** in **SETTINGS**. Enter the IP address or the host name of the WinMOS®300 in the window **WINMOS®300 SERVER SETTINGS**.



**Image 60**  
WinMOS®300 Monitoring provides a clear overview of lifts in real time.




**Image 61**  
To connect a controller via the intranet, WinMOS®300 PC only requires a network connection.



**Image 63**  
Activate this option to receive controller data from a WinMOS®300 server



**Image 64**  
Click on MODEM/INTERFACE to set a modem connection.



**Image 65**  
In this dialogue, select the COM-port via which the connection should be made.



**Image 62**  
The WinMOS®300 server's selection via the host name.

## 7.2.3 Connection via the Serial Interface

With the USB or serial interface on the computer the PC can connect to the controller via analogue modem, ISDN or direct serial connection with a zero modem cable or RS422 converter.

Click on the button MODEM/INTERFACE to set up a modem connection. In the dialogue which then appears, select the modem or COM-port through which the connection is to be made. Activate the option MODEM CONNECTION (ANALOGUE/ISDN) ....OR.... CONNECTION VIA ZERO MODEM CABLE and click the MODEM/INTERFACE button. A dialogue appears allowing selection of COM port or modem via which the connection takes place.

### 7.2.3.1 Extension

If you have to dial an »0« to get a line, activate this option. All of the telephone numbers stored in the database are then automatically assigned an »0,« when dialled.

### 7.2.3.2 Selecting a Modem

If your modem is correctly installed in Windows® you can select it by name from the list. Alternatively, mark the serial port (COMx), to which the modem is connected. Each USB modem which is set up on the PC appears by name in the list together with the COM port assigned by Windows®.

If you choose to amend the interface parameter between the PC and the modem just click on the field CHANGE SERIAL PARAMETER. A dialogue window opens allowing you to select whether the modem dials in tone or pulse mode. The tone mode is most commonly used. The pulse mode has only been retained for reasons of compatibility with older telephone systems. In EXTENDED, ADDITIONAL AT-COMMANDS you can enter commands which are sent to your modem on initialising. See your modem manual, if required. A common entry in this field is »M0« resp. »M1,«, which either mutes or silences the modem speakers.

Click on INTERFACE PARAMETER to change the setting on the interface to which your modem is connected, should this be required.

### Bits per Second

Set to the maximum transmission rate from modem to PC. If you have correctly installed your modem in Windows® and selected it in the list, this point does not apply. (For a 33600bps modem e.g. a bit rate of 57600bps).

### 7.2.3.3 Direct Connection PC / Controller with Zero Modem Cable

To connect the controller via a zero modem cable in a direct serial mode, connect to a free COM port on your PC; now set the connection setting of this port so it accords to the controller settings. (see controller manual).

### 7.2.3.4 ISDN

To use an ISDN connection you may use an external device or an internal ISDN card. If your computer is equipped with an ISDN card a Fossil driver must be installed. This driver translates the AT commands to the corresponding ISDN ones. An external ISDN device is approached like its analogue counterpart.

Not every ISDN card supports analogue telephone operation. Check with your specialist before purchasing an ISDN card / ISDN device. There are pure ISDN devices with which you can only connect to ISDN connections. There are also devices which are built for both connections modes (analogue and ISDN). We recommend these for monitoring controllers with analogue and ISDN connections.




▲ Image 66

Selecting a modem



▲ Image 67

The standard setting for present day telephone systems is tone dialing.



▲ Image 68

This window is for setting interface features



## 7.3 Program Settings


To adjust program settings, go to FILE menu and then select PROGRAM SETTINGS.

The settings are divided into 3 groups which are marked by symbols.

- ▶ Visual program settings
- ▶ Window actions for incoming malfunctions and screen savers
- ▶ Acoustic program settings
- ▶ Printing

**Image 69**

If the lift is running without faults the screen saver shows this symbol.



### 7.3.1 Visual Program Settings

- ▶ align controller time with PC time  
If this option is active the current time will be transmitted to the controller each time it is connected.
  - ▶ re-calculate building scale at each program start  
If this option is active the lift shaft display is re-calculated using the absolute value transmitter data at each program start.
- Furthermore, you can change the character set used for the pop stack, malfunctions list etc. or you can select a bold font in the dialogue window.

### 7.3.2 Acoustic Program Settings

Mark the fields on the left of the action to activate an acoustic signal. Enter the sound file to be played, to the right of the action. To simplify choosing the file name you can select a sound file (\*.wav) by clicking on the field marked with three points in the sound selection box.



**Image 70**

Fault free operation is signalled by this symbol on the screen saver.

### 7.3.3 Printing

#### PRINT IMMEDIATELY WHEN MALFUNCTIONS INCOMING

If you have an online connection to a lift and a malfunctions message comes in putting the lift »out of order« a protocol printout is immediately generated. You can determine if a full page is printed or just a line which includes only RD (remote data transmission) number and lift number. The latter printing method only works with matrix printers (fan-fold paper). Ink-jet-/laser printers work with single pages.

### 7.3.4 Window Actions for Incoming Malfunctions

This function allows you to set when WinMOS®300 is to appear automatically in the foreground. Furthermore, the active WinMOS®300 screen saver can be activated. This shows an »OK« symbol when the lift is connected to WinMOS®300 and there is no current malfunction, and a stop symbol in case of malfunction.

## 7.4 User Rights

To adapt user rights go to FILE menu and select SETTINGS, then choose USER RIGHTS.

Now you can determine which rights each user is assigned within WinMOS®300. The following controller functions can be activated or deactivated:

- ▶ Block floors,
- ▶ Place calls,
- ▶ Remote OFF/ON,
- ▶ Change lift parameters,
- ▶ Configuration mode,
- ▶ Delete malfunction stack / -list,
- ▶ Change call-back parameter.

Moreover, visualising functions can be set:

- ▶ Malfunctions / messages visible,
- ▶ Call field visible.

## 7.5 Set Up Connection to Lift

WinMOS®300 Monitoring constantly checks the connection to all lifts. If there is no connection to a lift, or the connection is interrupted, WinMOS®300 Monitoring initialises the connection again in cycle. If single lifts are connected via modem and no permanent connection is



▲ Image 71

A malfunction is signalled by this symbol on the screen saver.



▲ Image 72

Each user can be assigned various user rights.

desired then the dialogue box CONNECTION SETTINGS menu point MANUAL DIALLING/DISCONNECTING can be activated.

## 7.6 Monitoring View

The monitoring view shows the lifts side by side. The call field and the message field can be pulled down or pushed up in each lift window. Above the lift window you will find the lift status bar. In this field you find all lifts from this work place displayed as a symbol. A double click on a symbol opens the diagnosis view of the appropriate lift.

## 7.7 Diagnosis View

A double click on a lift window or a lift symbol in the lift status bar displays the appropriate lift in diagnosis view.

When connecting to a controller the lift window is filled with data sent by the controller. This window displays dynamic controller data in graphic form; the lift shaft, the car position, the safety circuit and other details are in the graphic layout. In addition, you will find all current messages, malfunctions, the pop stack and the list.

The display is divided into 3 parts:

- ▶ On the left is the field which includes all pending calls and blocked floors and the shaft display, which shows the dynamic movement of the car and the doors.
- ▶ In the middle is the database information and the dynamic lift data.
- ▶ On the right, 4 fields display the current messages and malfunctions, the pop stack and the fault list. If a web cam is connected it is also shown here when active.

### 7.7.1 Call Field

Following connection, the call field depicts all calls configured in the controller as meaningful symbols.


cabin call	no call		call active	
landing call	up		down	
floor	free		blocked	

The shaft display is to scale if the lift has an absolute copy mechanism (AWG, USP, ...). If it only has a magnetic switch copier then a standard shaft with a defined number of floors is shown. The car movements are also transmitted accordingly to the copy mechanism.




▲ Image 73

If there is no connection to a lift this is displayed by a red sign in the shaft.



▲ Image 74

The monitoring view present lifts installed next to each other.



▲ Image 75


All calls can be placed and floors blocked or released via this call field.

## 7.7.2 Data Field

The display is divided into individual sections which can be selectively hidden or shown.

- ▶ The section **DATABASE** shows the lift data from the data sheet. It contains the lift number, the operator, the manufacturer, the address and the remote data transmission number of the lift.
- ▶ The section **OPERATING DATA** informs of the current time and date, operating hours, number of trips, rope slip, temperature in the control cabinet and the current lift load. Some of this data can only be displayed if the lift is equipped with the appropriate sensors.
- ▶ **LIFT TYPE** – is the section where the basic lift information set in the controller is displayed, such as drive type, processor type, kind of doors and the controller. It is pointed out here if the remote data transmission data sheet number does not accord with the lift connected.
- ▶ In the section **SAFETY CIRCUIT AND SIGNALS** the safety circuit terminals and the status of the levelling, impulse- and correction signals are displayed as symbols.
- ▶ The section **STATUS** displays the function of the light grid, the direction arrows, the drive signal and the floor status. Furthermore, the status of the lithium battery on the processor unit is shown.
- ▶ The section **AWG/USP DATA** shows the current position, the deviation from levelling position and the current car speed if the lift is equipped with an absolute copying mechanism.
- ▶ The section **PRE-CONTROL DOORS** shows the pre-control door signals. If the controller has doors with limit switches then the conditions of the **DOOR LIMIT SWITCH OPEN** and **DOOR LIMIT SWITCH CLOSED** are shown as symbols next to the door motor indicators.
- ▶ In the section **INITIATE ACTIONS** are the buttons for the following actions: **DELETE POP STACK**, **DELETE FAULT LIST**, **RE-CONNECT** and **CHANGE CALL BACK PARAMETER**.
- ▶ The section **WEB CAMERA** has a button which connects you to the given website of a potential web cam. On activating the check box **EMBEDDED VIEW**, the web site is not depicted in its own window but on the right below the current malfunctions.

All sections can be overlaid via the check box on the right side. Use this option if your screen resolution does not allow display of all section at the same time.



**Image 76**

The data field shows the database and the dynamic lift data.



**Image 77**

This window shows the current lift messages.



**Image 78**

This data field displays the current malfunctions.


## 7.7.3 Messages and Malfunctions

On the right, in the lift window is the display for the information about pop stack, malfunction list, current messages and faults. Malfunctions and messages are only shown as long as they prevail. The windows **FAULT LIST** and **POP STACK** show records of previous malfunctions. This also includes the number of malfunctions resp. their date and time.




**Image 79**

The pop stack contains malfunctions with time stamp.



**Image 80**

This malfunction list shows the number of faults.



**Image 81**

The maintenance stack shows the maintenance information with time stamp.

## 7.8 Maintenance Stack

To view the maintenance stack select **VIEW** in the **MAINTENANCE STACK** menu. A window opens showing the last maintenance entries from the controller which was called.

### 7.8.1 Window Contents

The individual maintenance information is displayed using various symbols:

- ▶ Maintenance intervals are marked by a red circle.
- ▶ Other maintenance actions are marked by a green circle.

Each entry effects transmission of a personnel code (PKZ). This is used to identify the person who carried out the action. To use this option, activate on the controller. Following activation, a personnel code will be requested for each maintenance action (maintenance on) carried out. Actions carried out on WinMOS®300 are assigned a personnel code in the controller and recorded in the pop stack. This remote data transmission personnel code is transmitted when dialling a controller and is currently fixed with the abbreviation »WMOS«.

### 7.8.2 Controller Settings

When a maintenance interval point e.g. maintenance, operating hours or number of trips is reached, the controller or the remote data transmission device FDG-03 can emit a so-called maintenance call-back. This function must be previously set in the controller. Once set, the maintenance call-back is treated like a malfunction call-back, it is accepted and then recorded in the database.

## 7.9 Lift Attendant Status

To view the controller's lift attendant status go to VIEW and select LIFT ATTENDANT STATUS. The lift attendant status contains the current information which is transmitted from a controller + absolute value transmitter or in case of an alien controller, an electronic lift attendant module.

The lift attendant records can be retrieved via the RECORDS button. The following information is evaluated by the controller and transmitted to WinMOS®300:

### Extreme Non-Levelling in the Previous Week:

A second channel (i.e. an additional levelling switch) determines and counts up extreme non-levelling from the controller + lift attendant module(AWM02) / FDG-03.

### Light Barriers OK:

If there is no change in the light barrier signal for 20 consecutive trips then a malfunction is assumed and an appropriate message is generated.

### Light barriers present:

An appropriate abbreviation is entered for each light barrier (A = door A,...) to activate door monitoring.

### Car Light Monitoring OK:

Intelligent sensors in the lift attendant module resp. electronic attendant module analyse the car light electricity. The lift attendant status window shows the condition of the car light with yes/no for car light OK/faulty.

### Car Light Monitoring Active:

This entry shows if the car light monitoring feature is activated.

### Last Trip:


Here you find the date and time of the last proper trip. A proper trip is one where no malfunction occurs.

### Last Emergency Call:

Date and time of the last emergency call (pay attention to the emergency call delay time in the controller's basic menu).


### Maintenance Start:

Gives the date and time the last maintenance started.



▲ Image 82

The lift attendant window with the current lift attendant status data.




**Image 83**

Various parameter can be set in this window.



**Image 84**

You can enter telephone numbers for emergencies and emergency calls here.



**Image 85**

This window is for entry of maintenance interval values.

### Maintenance Finish:

Gives the date and time the last maintenance ended.

### First Proper Trip:

Gives the time and the date of the last proper trip following the last lift malfunction.

## 7.10 Remote Operation

Using WinMOS®300 you can make calls online, block floors, change lift controller parameter which are not relevant to safety, switch outputs and show input status.

## 7.11 Change Lift Parameter

Go to the PARAMETER menu and select CHANGE LIFT PARAMETER. Select the parameter group you wish to change from the dialogue box.

The label GENERAL encompasses the fundamental parameter; RD number, lift number, basic code, service code, remote data transmission password, trip number, operating hours and date, controller time. The controller's RD number entered here must comply with the appropriate data sheet in the WinMOS®300 database.

The label TELEPHONE NUMBERS offers various fields for entry. The controller uses these numbers for call-backs. If the first number cannot be reached the second number is dialled as long as there is a number entered in field 2. If there is no answer here, then the next number is dialled if a number has been entered in field 3.

The label MAINTENANCE allows definitions of various maintenance intervals. When these intervals are reached (e.g. 30000 trips) a message is sent to the central unit and the value is then increased to that of the next cyclical maintenance interval (e.g. 5000 trips). Thus, the controller signals the need for e.g. cyclical maintenance every 5000 trips. Cyclical interval values can be entered for the number of trips, the operating hours and a monthly interval.

The label SPECIAL FLOORS allows entry of parking stops, inspection stops, resting stops, fire stop, fire brigade stops, emergency power stops and the maintenance stop.

After setting the parameter the values must be sent to the controller by clicking on SEND. The field CLOSE closes the window without further storing the parameter in the controller.

## 7.11.1 Configuration Window

This window serves to configure the controller via WinMOS®300. It shows the display, the keys if available and the controller bargraph. This means all service menu parameter can be set in the native language on site. The configuration of the converter connected can also be carried out in DCP-mode. Activate it via `PARAMETER` → `CONFIGURATION` VIA THE `DISPLAY`.

The display content appears somewhat delayed in modem connections due to the restricted band width. So, please click slowly and wait for the text changes in the display.

`DCP-MODE ON/OFF` in the display menu can be activated when the controlled dialled is equipped with a converter which supports this mode.

The flip switch marked with `L-Call` (Landing Call), effects deactivation of remote data transmission to the landing call control. Deactivation of the landing call control in this option can only be changed via remote data transmission.



**Image 86**

The configuration window shows the service menu in WinMOS®300.



# 8 WinMOS®300 Emergency Call

## 8.1 Field of Application

WinMOS®300 Emergency Call provides the opportunity to administer and protocol incoming calls. The existing database from WinMOS®300 Diagnosis or Monitoring can be used making unnecessary upkeep superfluous.



**Image 88**

WinMOS®300 Emergency Call enable convenient administration of emergency calls with the telephone functions of a PC.

WinMOS®300 Emergency Call works with devices from various manufacturers. In some cases, there is a connection of the emergency call device receiver (Telegärtner, GS Elektronik) and other emergency calls can be received directly without extra hardware (Leitronic, TeleTech). In both cases the emergency call devices transmit the identification number of the emergency call location calling.

## 8.2 Setting Up Hardware

### 8.2.1 Emergency Call Devices without Receiver

To evaluate emergency calls received from devices which do not need a manufacturer's receiver WinMOS®300 uses telephone devices e.g. an ISDN card and the sound card in the PC. For optimal use a headset is recommended.


The telephone device used, runs through WINDOWS® via a TAPI-driver. It has to support the function "recognise call number and DTMF tone, send and receive". In this manual we, for example, use the ISDN card „AVM Fritzcard PCI 2.0“.

Set the card up according to the manufacturer's instructions. The MSNs are entered in the Windows® system controller showing which cards should be reacted to. Then, in the telephone settings from WinMOS®300 Emergency Call, select „AVM ISDN TAPI services (Cntrl1)“ from the list. Now, the connection number to which WinMOS®300 Emergency Call reacts is set. To do this click on the manufacturer's specific extended settings. The dialogue box which appears is provided by the ISDN card manufacturer drivers, see Image.



**Image 87**

The settings to the telephone interface are found in this dialogue box.




**Image 89**

The AVM card settings.



**Image 90**

An incoming emergency call is signalled by a red window.



**Image 91**

Device identification takes place after acceptance.



**Image 92**

After identification you can talk to the person calling.



**Image 93**

A green window shows the end.

Enter the main number (in our company +4922049553) and the extension (e.g. 644). Calls to this number are then transferred to WinMOS®300 Emergency Call.

Completely implemented devices with extended functions are currently:

- ▶ EasyAlarm ELEVATOR PLUS® (LEITRONIC AG),
- ▶ AUTODIAL 3100/5100® (TeleTech a/s).

## 8.2.2 Emergency Call Devices with Receiver

»GS Elektronik« and »Telegärtner« emergency call devices call external receivers. These internally transmit incoming messages and only transmit the status to WinMOS®300 via an internal Windows® interface. »GS Elektronik« have devices which require an appropriate DLL running in the background. »Telegärtner« devices require a special interface card »Moxa« and complete emergency call software.

The software for both devices was not running satisfactorily under Windows® XP at the time this manual was written. For this reason we recommend Windows® 2000 for use with these devices.

The following list provides an overview of the components required by the emergency call device manufacturers:

GS Liftvoice®:

- ▶ Liftvoice® Receiver device,
- ▶ Liftvoice® Receiver Software V1.2d

Telegärtner®:

- ▶ ANLZ 715 – emergency call centre,
- ▶ Software to emergency call centre (ANLZ) with software interface for WinMOS®300 (optional) .

## 8.3 Presentation of Emergency Calls, Symbols


An incoming emergency call effects a red window in the foreground. If an ISDN card is used and the telephone number can be evaluated then the lift data is displayed here.

After clicking the button ACCEPT EMERGENCY CALL the window turns yellow and WinMOS®300 Emergency Call begins retrieving data via DTMF tones. After this the device has been clearly identified and all lift data is shown in the window, the call is then automatically changed to speech mode. You can now speak to the caller.

A click on FINISH CALL sends WinMOS®300 Emergency Call the required data and the emergency call device discontinues the call. A


green window shows the call has been discontinued and that WinMOS®300 is ready for the next emergency call.

All incoming emergency calls are protocolled in the database and displayed in the emergency call window. New incoming emergency calls are clearly highlighted. Confirming new incoming calls is done with a double click on the entry/entries. Enter the name and comment in the window that then appears.



▲ Image 94

New incoming calls can be given a comment and then confirmed.



▲ Image 95

All incoming emergency calls are clearly displayed


WinMOS®300 Emergency Call protocols not only when a new call comes in but also when a call starts, ends and what action was taken.



▲ Image 97

The overview module shows an emergency call as a flashing symbol with exclamation mark.

WinMOS®300 Emergency Call works together with the overview module and WinMOS®300 Diagnosis / Monitoring. If an emergency call is signalled the appropriate car in Diagnosis / Monitoring and overview is marked with an exclamation mark. This mark is only removed when the highlighted entry is confirmed.




▲ Image 96

In WinMOS®300 Diagnosis an emergency call is shown as a red car with exclamation mark.



**Image 98**  
Individual settings for various emergency call devices can be made in this dialogue box.



**Image 99**  
This box is for extended settings.

## 8.4 Setting Up Emergency Call Receivers

### 8.4.1 Requirements, Program Settings

The settings box accessed via the FILE menu - SETTINGS, allows you to enter in the group emergency device settings those device types which are connected to the central unit.

The emergency call devices from different manufacturers communicate with the PC in the centre using differing protocols. Manufacturer dependent hardware is required to accept emergency calls. For example, the emergency call system »GS Liftvoice« requires a receiver which is connected to the PC via a serial interface. Telegärtner systems are similar. Products such as Leitronic »EasyAlarm« or TeleTech »AUTODIAL«, require an internal telephone-PC-card (e.g. an AVM Fritzcard PCI 2.0), which enables the PC to function like a telephone (with number recognition and DTMF tone reception / transmission). Further information about manufacturers specific hardware and software needed in connection with WinMOS®300 Emergency Call is available from manufacturers and from us. WinMOS®300 Emergency Call can operate all combinations of emergency call systems listed.

### 8.4.2 Test Call after Taking into Service

If you are using a telephone with tone dialling you can place a call to the emergency call PC after installing any connection. If the number transmission is active in an analogue connection, it is shown in the emergency call window and is completed by the PIN stored in the device during connection.

## 8.5 Further Settings

### 8.5.1 Send Automatic Confirmation to Emergency

#### Call Device

In this box you can select if the program should automatically send confirmation to the emergency call device. This feature is active as standard. When the user clicks on FINISH CALL the emergency call device automatically receives a message saying the call was accepted before the connection is interrupted. If this option is not active the user clicks the box FINISH CALL and is then required to define the next steps.

If the user defines there should be no confirmation sent to the emergency call device, then the next set telephone number is dialled and an attempt is made to place the emergency call there.

### 8.5.2 Setting for Accepting Check Up Call

The emergency call devices contact the central unit at a given set time. To differentiate whether the call is a real emergency call or just a communication check, both calls are sent to differing telephone numbers.

The telephone card used in the PC can react to several numbers (MSN). The program must, however, know which number is available for the communication test. It can be entered in TELEPHONE NUMBER FOR CHECK UP CALL in the service centre.


If a call (ringing tone) comes in on the telephone number assigned for the communication test then it is entered as communication test in the database and it has its own icon. A call to any other number is interpreted as an emergency call.

## 8.6 Communication Monitoring

Menu VIEW → OVERVIEW CYCLICAL CHECK UP CALLS


Set out in EN 81-28:

The emergency call unit must check the input signal via automatic simulation at such intervals as ensure the safety of the user during proper implementation of the lift. This must however be at least every three days (automatic check up) and the following connection to the emergency call centre must be established.




▲ Image 100

Activate automatic confirmation here.



▲ Image 101

The cyclical check up calls can be received in the background.




**Image 102**

Overview of cyclical emergency call check up calls

Check up calls which serve to conduct a communication test are automatically received by the software. The check up calls are forwarded to a second number by the emergency call devices. This can be on the same physical line as the central unit has several (ISDN) numbers available. This feature enables the software to instantly recognise if it is dealing with a communication test or a real emergency call.

The last check up calls are stored in the database. The overview can be displayed as a table which shows the user when the last check up call was incoming and when the next is expected. As soon as an emergency call device contacts for the first time it is listed. The program decides the next interval automatically based on the time set in **SETTINGS → TELEPHONE SETTINGS**. WinMOS®300 Emergency Call monitors the entries in this table. As soon as a device is due to generate a check up call, but fails to do this, then this is made visible to the user. The list can be sorted and printed. If you wish to remove a device from the list select **DELETE ENTRY** from the context menu (right mouse key).



**Image 103**

The colour legend helps the user recognise which devices have not signalled.

# 9 WinMOS®300 Circular Call Module

## 9.1 Field of Application

Together with call acceptance this circular call module is the ideal tool for optimising your maintenance. It is able to cyclically retrieve data from remote data transmission compatible lifts. The connection to each lift is checked and pop stack, malfunction list and lift attendant status are interrogated. Then a comprehensive protocol showing overall lift status is printed. You see immediately which lifts need attention and which are working properly. The circular call can be conducted via several modems or via an intranet.

## 9.2 Installation

If the circular call module is included in the scope of delivery. It will automatically be installed together with WinMOS®300 Diagnosis or Monitoring applications. The CIRCULAR CALL button appears in the WinMOS®300 StartCentre.

## 9.3 Settings

After clicking on CIRCULAR CALL in the WinMOS®300 StartCentre the module opens. Open the dialogue box and configure the settings for modems and printers. The telephone connection needs to know whether the modems are attached to an extension.

To select a modem for circular call go to FILE → SETTINGS. The window which opens allows you to mark which modems should be used.

A double click on the field next to the name opens a dialogue box which then allows you to enter the interface parameter manually. If the modem is correctly installed in Windows® you can confirm this box with No and the manufacturer's settings are used.

## 9.4 Setting Up Circular Call


The right half of the window lists the lifts from the database. The left half shows the circular call as a tree, in Explorer style.

To add a lift to circular call click on its RD number (remote data transmission number) in the database (right side of window) and drag it to the left window holding down the left mouse key. To configure, click the »+« symbol next to the RD number.




▲ Image 104

Select which modems are to be used for the circular call.




▲ Image 105

On the left are the lifts which are configured for the circular call, the database is on the right.



**Image 106**

A double click on „Change settings“ opens the configuration window for this call.



**Image 107**

These actions can be carried out for any call.



**Image 108**

The comprehensive overview shows the status of all lifts entered.

By clicking the CHANGE FEATURES a box opens allowing you to select the following:

- ▶ DELETE MALFUNCTION LIST to delete malfunction list during call,
- ▶ DELETE POP STACK to delete pop stack during call,
- ▶ TRIGGER TRIP to trigger and monitor a test trip. The trip is monitored until it arrives at the designated stop.
- ▶ If the option PRINT LIFT ATTENDANT STATUS is active, a malfunctioned test run will be noted in the protocol.
- ▶ In THRESHOLD FOR NON-LEVELLING the threshold value is entered which should trigger a message in the lift attendant status during the weekly circular call. This value is not considered if lift attendant status - print is not active.
- ▶ If the controller and the emergency call device share a telephone connection the option EMERGENCY CALL DEVICE SELECTOR SWITCH (LAS) effects that after the call the controller immediately disconnects, and is re-called if the emergency call device necessitates it.
- ▶ Block or release floors,
- ▶ Remote lift operation REMOTE OFF/ON,
- ▶ Or automatic printout of transferred stack entries and deletion in lift.

## 9.5 Comprehensive Overview

The compressive overview is found in VIEW → COMPREHENSIVE OVERVIEW on screen. It provides an overview of the remote data transmission status of all lifts entered in circular call. You can readout which lifts were last interrogated, if remote data transmission failed and circular calls were postponed. There is a legend which explains the symbols at the bottom edge of the window.

## 9.6 Activating the Automatic Circular Call

After setting all parameter activate circular call by clicking on the field AUTOMATIC CIRCULAR CALL. Activation is shown via a colour and text change in the status field. The system now acts according to the time and day set. If a remote data transmission connection cannot be made the system is postponed for 10, then 20 and finally 30 minutes, if it fails again it is then postponed to the next day. If the connection succeeds then the next call is made at the time and date set.

## 9.7 Lift Attendant Status

If BÖHNKE + PARTNER's controllers are equipped with the AWM-02 (lift attendant module) or other manufacturer's controllers using an remote data transmission device FDG-03, the lift attendant data is transferred with each call and stored in the »AWS« directory. They can be retrieved in the database window via MALFUNCTION FILE → AWS.

The following information is evaluated and transmitted to the controller:

- ▶ Extreme non-levelling in the previous week:  
With the aid of an additional levelling switch non-levelling is detected and accumulated by the FDG. If the set threshold is exceeded within a week an appropriate message is transmitted.
- ▶ Light barriers OK:  
If no change in the light barrier is detected within 20 consecutive trips, it is assumed there is a malfunction and the appropriate message is transmitted.
- ▶ Light barriers equipped:  
An appropriate abbreviation is entered for each light barrier equipped, (A = door A,...) to activate light barrier monitoring.
- ▶ Car light monitoring OK:  
yes / no represent car light OK / malfunctioning
- ▶ Car light monitoring active:  
This entry shows if the car light monitoring facility is active.
- ▶ Last trip:  
Date and time of the last proper trip:
- ▶ Last emergency call:  
Date and time of last emergency call (please take note of the emergency call delay time in the controller basic menu)
- ▶ Maintenance begin:  
Date and time of the last maintenance begin
- ▶ Maintenance end:  
Date and time of the last maintenance finish
- ▶ First proper trip:  
Date and time of the first proper trip following a malfunction.

Circular Call		Page 1	25.12.2004, 15:09:55
<b>Attendant Circular-Call-State</b>			
Lift:	"Europa 1"		
RD number:	"euro1"		
Phone number:	"41"		
Street, City:	"Industrieweg 13, Bieleberg"		
AWS state of 29.12.2004, 15:09:47			
Extreme non-levellings:	0		
Light barriers present (A,B,C):	A - -		
Light barriers state (A,B,C):	A - -		
Cabin light check active:	yes		
Cabin light state:	yes		
Last Drive:	29.12.2004, 15:07:02		
Last emergency call:	- - - - -		
Begin last maintenance:	- - - - -		
End last maintenance:	- - - - -		
First drive after malfunction:	04.08.2004, 18:29:58		
Call to RD number "euro1", connection at 2.try			
Online time: 9 minutes and 14 seconds			
power on time: 90 drive count: 41029			

▲ Image 109

Example of a printout of the lift attendant status circular call status.

Record	Location	Date	Status
EUROPA 1	Industrieweg 13, Bieleberg	25.12.2004, 09:11:12	Extreme non-levelling: 0
EUROPA 2	Industrieweg 13, Bieleberg	25.12.2004, 09:11:12	Extreme non-levelling: 0

▲ Image 110

A double click on an entry in the database overview opens the circular call records.

## 9.8 Protocols

Each time a system is successfully contacted a lift attendant status protocol is printed, if this option is activated in `PRINT LIFT ATTENDANT STATUS PROTOCOL`. The sheet comprises all relevant information (see Image).

Additionally, a protocol with an overview of all systems contacted, is printed. This protocol shows which systems were called and if these systems must be checked. Systems are marked for `CHECK` if:

- ▶ the number of extreme non-levelling incidents is greater than the value set,
- ▶ no RD connection possible,
- ▶ the system is out of order,
- ▶ a test trip was not successfully carried out,
- ▶ there was an emergency call in the last week,
- ▶ car light / light barrier defective,
- ▶ a maintenance due date has been reached.

lift	RD-No	date/time	City
Europa 1	euro1	29.12.2004, 15:00:47	Industrieweg 13 Bensberg
Europa 2	euro2	29.12.2004, 15:01:53	Industrieweg 13 Bensberg
Europa 3	euro3	29.12.2004, 15:02:11	Industrieweg 13 Bensberg

The printout time can be set in the window. It can take place as soon as a sheet is full, at a defined time or as soon as the program is idle.

### ▲ Image 111

The lift attendant status circular call protocol gives an overview of all systems called.

# 10 WinMOS®300 Call Acceptance

## 10.1 Field of Application

Call acceptance serves the automatic acceptance of malfunctions, maintenance or message calls and the forwarding of these calls via email, text messaging (SMS) or Web service. The call-backs can be taken and forwarded via the telephone network or an intranet. All processes are recorded in the database.



## 10.2 Installation

If the call acceptance is a component of WinMOS®300 Diagnosis and Monitoring in the full version it is automatically installed together with these applications. To activate this click the CALL ACCEPTANCE button in the WinMOS®300 StartCentre.

## 10.3 Setting Up a Controller

If certain messages, malfunctions, emergency calls and the transmission of maintenance information appear, the controllers, remote diagnosis devices and electronic attendant modules can call the WinMOS®300 PC and transmit this information. Some conditions must be fulfilled before a controller with system module BP30x / BP11x can call a WinMOS®300 PC and trigger a malfunction message. The controller must be equipped with a modem which is able to connect to the public telephone network or have an intranet connection. The call-back must be activated on the controller and a call-back number must be set in the basic menu.

Enter the call-back numbers in basic menu as follows:

```
* Diverse                <CR>
* Basic code / div. numbers  <CR>
* Div. numbers           <CR>
+ telephone no.1        <CR>
```

...

Activate the call-back on bp11x / bp30x...


Enter the following settings in the service menu:

```
* Diagnosis              <CR>
* malfunction stack      <CR>
* DFU300/WinMOS         <CR>
+ call-back              <CR>
<if lift malfunctions> / <if lift blocked>
```




**Image 112**

The call-back can be triggered in 3 ways.



**Image 113**

Various emergencies can trigger a call-back.



**Image 114**

The call-back threshold can be individually defined for many malfunctions.

We urgently recommend provoking a test malfunction after setting up the controller to see the first call-back in the controller's display

- \* Diagnosis <CR>
- \* malfunctions /messages <CR>
- \* messages <CR>

where MODEM OK must be shown. Provoke a malfunction to test the call-back. The display now shows MODEM CALLS BACK. After successful connection you can read MODEM CONNECTED. After a few seconds the data has been transferred and the message DISCONNECTING MODEM is shown then MODEM OK appears again.

For detailed instructions please consult your manufacturer's manual.

### 10.3.1 Parametering the Call-Back

After connecting to a controller with WinMOS®300 Diagnosis a button is shown in the shaft window, it is marked CALL-BACK. Using this you can exactly parameter the call-back.

Select from the 3 possibilities:

- ▶ NEVER,
- ▶ IF LIFT MALFUNCTIONS,
- ▶ IF LIFT IS BLOCKED.

The first possibility effects deactivation of the call-back. The second effects a call-back for every malfunction and the third leads to one call-back if the malfunction has lead to a blocking of the system.

### 10.3.2 Behaviour in Emergencies

In various emergencies a call-back can be sent to a separately selectable emergency number. Which emergencies trigger a call-back can be individually set for each controller.

### 10.3.3 Parametering the Call-Back

After connecting to a controller with WinMOS®300 diagnosis a button is shown in the shaft window, it is marked „call-back“. Using this you can exactly parameter the call-back.

Select from the 3 possibilities:

- ▶ NEVER,
- ▶ IF LIFT MALFUNCTIONS,
- ▶ IF LIFT IS BLOCKED.

The first possibility effects deactivation of the call-back. The second effects a call-back for every malfunction and the third leads to one call-back if the malfunction has lead to a blocking of the system.

### 10.3.4 Behaviour in Emergencies

In various emergencies a call-back can be sent to a separately selectable emergency number. Which emergencies trigger a call-back can be individually set for each controller.

## 10.4 Setting Call-Back Parameter

Press the button **PARAMETER** to access a dialogue box where parameters can be set for each malfunction – if and when a call-back should be triggered. Multiple entries can be made for each malfunction so that e.g. call-back takes place only every 5th time. In addition, the user can designate whether a call-back is made every fifth time or only once. The next call-back is only placed after the user has intentionally called the system with WinMOS®300 Diagnosis and the malfunction subsequently occurred again. The call-back parameter set can be saved to a file by clicking on **SAVE**, **PRINT** prints out a protocol for your records.

### 10.4.1 Trigger Test Call-Back

This button effects a test call-back from the controller. After activation please wait for confirmation from the controller, interrupt the call and start call acceptance. The controller calls back within a minute.

To receive call-backs from the controller WinMOS®300 Call Acceptance must be started.


### 10.4.2 Setting Up a Modem

A click on **SETTINGS** opens a dialogue box where all program settings can be carried out. A further click on **CALL ACCEPTANCE MODEM / INTERFACE** in this window opens another window in which the modem for call acceptance is selected.

WinMOS®300 Diagnosis or Monitoring and the call acceptance are in a position to commonly use a modem meaning the same modem can be set in both programs.


A status window in WinMOS®300 Diagnosis or Monitoring can be overlaid via the **STATUS WINDOW** button. If the modem was recognised and correctly installed the status window shows the information as in the Image. A click on **DISCONNECT** initialises the modem again.

The program is now in the position to accept incoming calls.



**Image 115**


Selecting the modem for call acceptance.



**Image 116**

The modem interface status window.

## 10.4.3 Printing



**Image 117**  
Printer settings for incoming call-backs.

To adapt the printer option open **SETTINGS** again. On the upper edge of the window you can define how an incoming malfunction is to be handled. The option **PRINT MALFUNCTIONS LINE BY LINE** commands the program to print one line for each malfunction call-back on fanfold paper. This setting is recommended for a protocol printout which includes as many calls as possible. A matrix printer is required for this option as this is the only type of printer which allows line printouts. **PRINT MALFUNCTION PAGES** is to be used in case of ink-jet or laser printers. Each incoming call then leads to a one page printout, providing not only the malfunction text but also an extract from the controller's data sheet. If no printout is required click on **No PRINTOUT**.

### Forwarding

The software is able to forward incoming malfunctions to a mobile phone, as a text message or as email to an email system installed in a PC. Furthermore, an entry can be made in an internet database using a web service.

#### 10.4.3.1 SMS

It is possible to set up a modem especially for this, as it means WinMOS®300 is receptive for further malfunctions during forwarding. Enter your network operator, define the responsible fitter's mobile number and the SMS business number. The business number is defined by the operator and is automatically dialed by the network / operator. Changing this number is only necessary when the operator does this and when a digit for an outside line is required. The check box **FORWARD VIA SMS** must be clicked for this option. A click on **SMS TEST** generates a test call with the data given; an easy way to check settings.

There are two ways of assigning a mobile number. A global mobile number is entered in **MOBILE NUMBER**. If **NUMBER, MOBILE PROVIDER NETWORK FROM LIFT DATA SHEET** is active, the mobile number entered in the data sheet from the resp. lift calling, is used.

#### 10.4.3.2 Email

To be able to forward the incoming malfunction as email there must be an email system on the server. Tick the box **FORWARD VIA EMAIL** and define the email recipient in the field below. A test button sends a test email.



**Image 118**  
Configuration for SMS forwarding.

### 10.4.3.3 Web Services

If you would like to display the condition of all lifts on the internet you need a web server which provides the database information as a web page and which also administers user rights. Such a web server is operated by Softlab GmbH at [www.Liftbetrieb.de](http://www.Liftbetrieb.de). The server address (URL) must be entered before incoming malfunctions or maintenance messages can be forwarded to it. A central web server for all lifts can be entered or one each for every lift on the data sheet. The PC to which the call acceptance runs requires a permanent internet connection for this service. After arrival of the call-back this is automatically transmitted to the web server.

### 10.4.4 Night Control

WinMOS®300 allows suppression of forwarding at certain times. It seems sensible to only forward the malfunction when the service centre is not occupied. The time setting affects email and SMS-forwarding.

### 10.4.5 Archiving

In service centres with multiple connections, data volume can become extremely large. The automatic archiving function for old data is designed for this.


## 10.5 Using Call Acceptance

When everything has been set up all call-backs arrive at call acceptance. Here they are shown in list form. A new entry is found in bold print. As in the illustration, each entry is recorded with date and time. A double click on a new entry allows entry of a name and comment as confirmation.




▲ Image 119

Configuration of server address for the web service.




▲ Image 120

Configuring the night control



▲ Image 121

Configuration for automatic archiving.



▲ Image 122

Each call-back can be confirmed and protocolled with a comment.

RD No	Lift Id	Date/Time	Malfunction	Transmitted	Confirmation	Measure	Reception	SMS	Email	State
<b>eur01</b>	<b>Europe 1</b>	<b>03.11.2005/08:52:00</b>	<b>emergency stop (as malfunction)</b>	<b>03.11.2005/08:52:27</b>	...	...	...	not active	not active	new!
<b>eur02</b>	<b>Europe 2</b>	<b>03.11.2005/00:46:43</b>	<b>malfunction PTC-resistor</b>	<b>03.11.2005/00:47:09</b>	...	...	...	not active	not active	new!
eur03	Europa 3	03.11.2005/00:42:00	cabin light power	03.11.2005/00:43:26	Jorge Clafson	M. Kopejau informed	03.11.2005/00:43:34	not active	not active	is read
eur03	Europa 3	03.11.2005/08:37:17	malfunction PTC-resistor	03.11.2005/08:37:44	Roy Schneider	send a technician	03.11.2005/08:42:26	not active	not active	is read
eur04	Europa 4	03.11.2005/08:34:21	malfunction PTC-resistor	03.11.2005/08:34:49	Marzo Felo	Mrs. Kuna informed	03.11.2005/08:28:08	not active	not active	is read
eur04	Europa 4	03.11.2005/08:33:55	cabin light power	03.11.2005/08:34:07	Marzo Felo	sent a technician	03.11.2005/08:27:44	not active	not active	is read
eur04	Europa 4	03.11.2005/08:30:11	malfunction PTC-resistor	03.11.2005/08:30:39	Marzo Felo	sent a technician	03.11.2005/08:27:16	not active	not active	is read
eur04	Europa 4	03.11.2005/08:22:46	governor contact	03.11.2005/08:24:45	Ray Schneider	sent a technician	03.11.2005/08:51:29	not active	not active	is read
eur01	Europa 1	03.11.2005/08:19:54	emergency stop (as malfunction)	03.11.2005/08:21:27	Bernhard Lazar	sent a technician	03.11.2005/08:21:48	not active	not active	is read
eur03	Europa 3	03.11.2005/08:19:47	emergency stop (as malfunction)	03.11.2005/08:23:45	Higgins	sent a technician	03.11.2005/08:26:50	not active	not active	is read
eur02	Europa 2	03.11.2005/08:19:32	malfunction PTC-resistor	03.11.2005/08:19:58	Muri Lisa	M. Smith informed	03.11.2005/08:20:39	not active	not active	is read
eur04	Europa 4	03.11.2005/00:10:00	emergency stop (as malfunction)	03.11.2005/00:10:27	Kuno Kampa	false alarm	03.11.2005/00:10:50	not active	not active	is read
eur02	Europa 2	03.11.2005/00:10:07	malfunction PTC-resistor	03.11.2005/00:14:00	Kuno Kampa	sent a technician	03.11.2005/00:10:10	not active	not active	is read
eur01	Europa 1	03.11.2005/08:10:53	governor contact	03.11.2005/08:11:20	Kuno Kampa	sent a technician	03.11.2005/08:13:06	not active	not active	is read
eur01	Europa 1	03.11.2005/08:06:46	emergency stop (as malfunction)	03.11.2005/08:07:15	Michaels Piaza	sent a technician	03.11.2005/08:11:36	not active	not active	is read
eur03	Europa 3	03.11.2005/08:03:52	cabin light power	03.11.2005/08:04:19	Thomas Magnum	sent a technician	03.11.2005/08:26:27	not active	not active	is read
eur01	Europa 1	03.11.2005/08:02:54	emergency stop (as malfunction)	03.11.2005/08:03:21	Aleen Kastner	sent a technician	03.11.2005/08:10:48	not active	not active	is read
eur02	Europa 2	03.11.2005/08:02:27	malfunction PTC-resistor	03.11.2005/08:02:53	Kathrin Kasner	sent a technician	03.11.2005/08:06:17	not active	not active	is read
eur05	Europa 5	03.11.2005/08:01:52	governor contact	03.11.2005/08:02:10	Fajna Bali	sent a technician	03.11.2005/08:05:41	not active	not active	is read
eur04	Europa 4	02.11.2005/16:30:17	malfunction PTC-resistor	02.11.2005/16:30:36	Inna Kruger	M. Smith informed	03.11.2005/08:04:50	not active	not active	is read
eur04	Europa 4	02.11.2005/16:28:40	malfunction PTC-resistor	02.11.2005/16:29:01	Thilo Kruger	sent a technician	03.11.2005/08:04:39	not active	not active	is read

▲ Image 123

New entries in call acceptance are shown in bold print.

# 11 WinMOS®300 Statistic Module

## 11.1 Field of Application

In conjunction with WinMOS®300 Monitoring this module provides the opportunity of statistically preparing and presenting values collected via monitoring from lifts which are connected. This only deals with examples of statistical evaluation. The data can be retrieved from the database and evaluated using any standard Office application.



## 11.2 Legends and Navigation

Lift data is constantly monitored by WinMOS®300 Monitoring and written in the database with a granulation of 15 minutes.

Evaluations can cover differing periods. Displaying data over a 24 hour period shows a graph which pertains to a specific day. The date can be selected from the calendar.

The starting or ending date can be entered for presentation of a set time period. The graph then reflects this period.

The operating status columns are displayed in different colours. The blue column shows the period in which the lift was available without malfunctions.

The yellow column shows the time the maintenance was activated but where the lift was available for use.

The purple column shows the period the maintenance was active and the lift was not available for use.

The red column shows the period the lift was not available due to malfunction or de-activated external call controls.

## 11.3 Image Presentation

Select the view for statistical evaluation in the left tree. The evaluation is divided into 4 groups.




**Image 124**

Navigation bar for displaying evaluations over a 24 hour period.



**Image 125**


Navigation bar for evaluations which cover a set period of time.



**Image 126**


Legend of operating status.

## 11.3.1 Trips, Stops and Waiting Times




▲ Image 127


The selection tree for statistical evaluation.




STOPS PER FLOOR shows the number of floor-related stops in a set period. This evaluation is useful for floor related calculations.




NUMBER OF TRIPS - DAILY DISTRIBUTION shows the frequency of trips to each floor over the 24 hours in a day, in a definable period. Peak traffic can be identified and park and waiting floor can be assigned.




NUMBER OF TRIPS shows the controller trip counter over one day.




OPERATING HOURS shows the controller operating hours over one day.



CALL WAITING TIMES shows the average call waiting time over one day. The individual averages are detected with a granularity of 15 minutes. The average call waiting time is the average time from placing a landing call to the arrival of the lift at the desired floor. This shows the lift efficiency.




STOPPING DELAY TIME shows the average stopping delay time over one day. The individual averages are detected with a granularity of 15 minutes. The average stopping delay time is the time from stopping to starting, including door movement.




TRIP TIME shows the average trip time over a day. The individual averages are detected with a granularity of 15 minutes. The average trip time is the time which the lift needs on average to travel from one levelling impulse to the next.

### 11.3.2 Door Movements

The movement of three doors is detected via WinMOS®300 Monitoring and written in the database.




TOTAL DOOR MOVEMENTS shows how the number of door movements is distributed between the individual car doors. This enables conclusions as to car door loading.




DOOR MOVEMENTS PER FLOOR shows the door movements on each floor. This enables conclusions as to outer doors loading.

### 11.3.3 Further Time-Dependent Values


These values are usually dependent on the existence of special sensors to capture measurement values.




CONTROLLER TEMPERATURE shows the temperature graph in the controller over one day. A temperature sensor in bp306 sends this value cyclically. This measurement is especially interesting on hot summer days.




CAR OPERATING LOAD shows the load transported over one day. The individual averages are detected with a granularity of 15 minutes. A separate load measurement sensor is required for this.



ROPE SLIP shows the average rope slip of a rope lift travelling at constant speed over one day. The individual averages are detected with a granularity of 15 minutes. This value reflects the quality of the ropes and the sheave. A separate sensor is required for this.




OPERATING STATUS shows the lift condition at a glance. The columns show the times in which the lift is available, in maintenance or faulty. Furthermore the MTBF and the MDT is calculated and emitted. The time frame for evaluation is freely selectable.



FREE CHANNEL 1 - 5 can be used to transfer up to 5 time-dependent, individual measurement or conditions and store them in the database.

### 11.3.4 Further Location-Dependent Values



FREE CHANNEL 1 - 5 can be used to transfer up to 5 location-dependent, individual measurements or conditions and store them in a database.

# 12 WinMOS®300 Overview Module

## 12.1 Field of Application

The Overview module from WinMOS®300 – formerly (ZLT-Module) – is an extension of WinMOS®300, which enables a clear overview of all systems connected, shown on a scalable layout. To set up the cards resp. layouts and the positioning of the lifts you will require graphics as BMP-files.

The overview module is mainly used in lift company service centres or in technical centres within self-contained building complexes where staff instantly need to know lift positions.

## 12.2 Installation

If the overview module is part of the application package, you will find the button for this module after the set up in the WinMOS®300 Start-Centre. Click on the button to start the overview module.


Following the first overview start you will be asked to enter the first overview plan. This is the plan with the largest scale e.g. the map of Europe. In this plan you can set up more detailed maps of different countries and towns

Click the right mouse key on the overview plan and a menu appears. Select CHANGE OVERVIEW PLAN and enter editing mode. You will recognise this mode by the flashing font ENTRY MODE in the top left window corner. If a password has been agreed this will now be requested.

### 12.2.1 Add Lift Symbol


Click the right mouse key on the plan in edit mode and the following menu appears:

- ▶ ENTER NEW LIFT IN PLAN  
Create a new lift in the overview. Follow the box which appears.
- ▶ END EDITING MODE  
Ends the entry mode and returns to the normal operating condition.
- ▶ CHANGE SETTINGS  
Enables amendment of RD number and symbol labelling.
- ▶ EXPORT MARKING TO DISKETTE  
All lift symbols and the contents entered are exported to diskette.
- ▶ IMPORT MARKINGS FROM DISKETTE  
All lift symbols and the contents entered are read in from diskette.



▲ Image 128

The lifts are displayed as symbols on the layout in the overview module.




▲ Image 129

Edit mode allows addition of new lift symbols or detailed plans.




**Image 130**

Enter the new lift symbol's system data.



**Image 131**

Enter data of detailed plan.



**Image 132**

The overview plan shows the detailed lift plans and symbols.

Select ENTER NEW LIFT IN PLAN. A dialogue box opens and the following lift system data is entered:

- ▶ a brief description which appears above the lift symbol,
- ▶ a detailed description which appears when you move the mouse over the symbol,
- ▶ the RD number which establishes the symbol's connection to the database,
- ▶ an individual lift symbol which depicts the lift in the plan.

Then you can drag the symbol to the position on the plan where the lift is located.

## 12.2.2 Add Detailed Plan

Using entry mode and holding down the left mouse key, opens a square in which a link to an additional graphic can be made. A click on this field with the right mouse key opens a menu. Select ADOPT MARKING to change the marking to a link. The following dialogue box requests entry of the name of the link and the name of the graphic file (in bitmap format) which appears when the link is clicked on. If you are not in entry mode clicking on the link (left mouse key) effects branching into the new plan. Further lift symbols can be set up here.

## 12.3 Visualisation and Navigation

After leaving edit mode the overview module shows the detailed plans as dark rectangles, it also shows the symbols for the lifts that are set up. If the detailed plans are set up symbols for navigation appear in the symbol bar enabling you to zoom in and out. To zoom in, click the left mouse key on the rectangle. To zoom out, click the RETURN key in the navigation bar.

To connect to a lift double click the lift symbol and WinMOS®300 Diagnosis and Monitoring open with the connection.

If a malfunction comes into call acceptance the lift symbol starts flashing in red. A double click on the symbol directly checks which malfunction it is.

If an emergency call is coming into WinMOS®300 Emergency Call, the lift symbol starts to flash in red and an exclamation mark ( ! ) is additionally shown next to the symbol. A double click on the symbol directly checks which malfunction it is.

If the lift with the malfunction resp. the emergency call is not depicted on the overview plan, but on a detailed plan, then the detailed plan starts flashing. There is an optional setting where the detailed plan is automatically brought to the foreground in case of incoming malfunction.

The flashing stops when the call acceptance resp. WinMOS®300 Emergency Call confirms the incoming message.



▲ **Image 133**

For an incoming malfunction, the detailed plan can automatically be brought to the foreground.



▲ **Image 134**

An emergency call is shown by a flashing symbol and exclamation mark in the overview module.




## 13 Installation Examples

At this point we provide you with an overview regarding installations in differing cases. These are just a small number of examples to serve as a basis for your own projects.

### 13.1 Service Centre with WinMOS®300 Diagnosis

The most common application for WinMOS®300 Diagnosis is shown in the image. The controllers are equipped with a modem and connected to the analogue telephone network. In case of malfunction or maintenance the controller calls the WinMOS®300 PC and transmits this information. This can then be forwarded via SMS or email. If required, the controllers can be called from the service centre.



#### ▲ Image 135

Example of an installation of WinMOS®300 Diagnosis.


WinMOS®300 Diagnosis is usually extended in the service centres by the Circular Call module and the Overview module. The Circular Call module is required for the electronic lift attendant function. It runs in the background, checks the systems cyclically and prints protocols.

## 13.2 Service Centre with WinMOS®300 Emergency Call

To be able to receive emergency calls with WinMOS®300 Emergency Call the PC requires an ISDN connection with 2 MSNs. The PC can then receive the genuine emergency calls on one number while the other number takes the test calls in the background.

WinMOS®300 Emergency Call PCs are usually, additionally equipped with the Overview module.

If required, the WinMOS®300 PC can be additionally equipped with a modem and together with WinMOS®300 Diagnosis it can receive the malfunction and maintenance information, as described in the previous chapter.




▲ Image 136

Service centre with WinMOS®300 Emergency Call and WinMOS®300 Diagnosis.

### 13.3 WinMOS®300 Monitoring in the Intranet

There is usually an intranet infrastructure available in self-contained building complexes. This can be used to monitor the lifts making the time-consuming laying of cables unnecessary.

WinMOS®300 Monitoring is mainly used in conjunction with the Overview module and the Statistics module. If regular test runs, protocol printouts or the blocking and releasing of floors are required, then the Circular Call module is also used here.




▲ Image 137

All the time WinMOS®300 Monitoring is online with the lift controllers via the intranet.

## 13.4 WinMOS®300 Monitoring Direct Serial and Emergency Call

If connecting the lifts is not possible via intranet, cables must be laid from each controller to the service centre in a star-like way. This solution is more time-consuming and the workstation cannot be easily moved.

The image shows a combined solution; WinMOS®300 Monitoring direct serial and WinMOS®300 Emergency Call via an internal telephone installation.




▲ Image 138

Service center with WinMOS®300 Emergency Call and WinMOS®300 Monitoring and a direct serial connection to the controllers.

## 13.5 WinMOS®300 Monitoring with VPN

### 13.5.1 Principle of the dialup into a monitoring-net

If external remote diagnostics to execute in a local monitoring network, a connection to the lifts over a safe VPN connection is possible.





▲ **Image 139:**



WinMOS®300 Monitoring with a connection to the Intranet and the dialup of a service center with WinMOS®300 Diagnosis over VPN connection.



## 13.5.2 Server setup


To setup the server connection, you proceed please as follows:




























### 13.5.3 Client setup



To setup the client connection, you proceed please as follows:
















## 14 Concluding Remarks

The individual WinMOS®300 modules and applications are constantly under further development. If you should notice a function which is not described in this manual, please refer to our homepage <http://www.WinMOS.de> or order our latest manual.

### 14.1 Important Tips and Remarks

#### Meaning of RD (Remote Data Transfer) Numbers

The RD numbers have a special meaning. They are the unique index in the WinMOS®300 Database in which all controller data is stored. Please make sure the RD number in the WinMOS®300 Database is identical to that in the controller (basic menu). Only then WinMOS®300 can assign incoming call-backs to appropriate controllers on the controller data sheet. The RD number also serves as a file name. Thus, the malfunction of RD number „BP5061“ is stored in the „BP5061.mf“ file.

#### Demo Version Restrictions

The WinMOS®300 Diagnosis demo version can only effect a modem connection to our company's demo controller. Functions are not restricted so you gain an impression regarding software facilities. WinMOS®300 Monitoring and Emergency Call do not have demo versions at present as it would be pointless to demonstrate without connection to lifts or emergency calls. If you are interested in a demonstration please agree an appointment with us.


#### Service Version Restrictions

No new data sheet can be added to the database in the service version of WinMOS®300 Diagnosis. You must process the existing data sheet to create a general data sheet for your controllers. As all data is assigned to this data sheet the functions of this service version are restricted to fitter's applications, such as reading out system data and transmitting it to the service centre.

#### Registration and Dongle

Generally, a registration of all WinMOS®300 applications is necessary via internet. If requested, the applications can be equipped with a dongle for various interfaces. Large centres and large software deliveries are generally equipped with a dongle.

To register the software automatically the PC requires an internet connection. If this is not available manual registration can be carried out on the web page [www.WinMOS.de](http://www.WinMOS.de) → [registration](#). To ensure cor-



▲ Image 140

For manual registration please fill in all fields on the [WinMOS.de](http://www.WinMOS.de) website. You will receive a code which enables you to activate the application.

rect functioning please fill out all fields correctly. You receive a code which you enter in WinMOS®300 to activate registration.


### Languages

WinMOS®300 is available in various languages. The software is developed in German and English and then professionally translated into the respective languages. Program parts which are not available in a specific language are shown in English. We make the effort to keep up to date in all languages. If, however, you should find an incorrect translation, please notify us and we will rectify this immediately.

[info@WinMOS.de](mailto:info@WinMOS.de)

## 14.2 Webpage

There is a web page for the WinMOS®300 pack at [www.WinMOS.de](http://www.WinMOS.de). It is constantly updated and you will find information about current software changes, new features and special solutions.



▲ Image 141

You will find the latest information round about WinMOS®300 on the internet at [www.WinMOS.de](http://www.WinMOS.de).



# Index

Access	10f.	Preface	7
Acoustic Program Settings	24, 38	Printing	39
acoustic signal	24	Program Settings	38
alarm plan	11	pulse mode	21
AT-commands	21f.	RD number	24
Block floors	25	real-time monitoring	9
Borland® OWL	9	registration	11
building complexes	14	Remote OFF/ON	25
Building Scale	24	screen saver	23, 25
call-back parameter	25	Server	23
CANopen	11, 16	sound file	24
capacity profile	15	Statistics module	75
Circular Call module	73, 75	Statistics Module	15
Circular Call Module	14	Synchronisation module	11
clients	23	Synchronisation Module	15
COM port	21f.	TCP/IP	23
comserver	23	telephone network	73
Configuration	25	telephone number	21
Configuration Window	45	telephone system	21
database	11, 14, 21	tone mode	21
Database	13	transmission rate	22
dBase IV	10	USB modem	21
Diagnosis	13, 73	user rights	39
Direct Connection	37	Version 4.0	9
direct serial	76	Visual Program Settings	24, 38
Emergency Call	14, 74, 76	Zero Modem Cable	22, 37
Fossil driver	22		
group overview	11		
host name	23		
interface parameter	21		
Interface Parameter	22		
internet	14		
internet portal	11		
intranet	23		
Intranet	75		
IP address	23		
ISDN	22, 37		
ISDN connection	74		
laser printer	24		
lift number	24		
line	21		
maintenance	7		
maintenance information	74		
MFC	9		
Microsoft®	10		
modem	73		
Monitoring	14, 75ff.		
network	14		
Network	23		
network card	23		
Overview module	73ff.		
Overview Module	15		
Place calls	25		
Plug Ins	16		
point-to-point connection	23		

