



**EN** Operating instructions . . . . . pages 1 bis 18  
Original

**Content**

**1 About this document**

1.1 Function . . . . . 1

1.2 Target group: authorised qualified personnel . . . . . 1

1.3 Explanation of the symbols used . . . . . 1

1.4 Appropriate use . . . . . 2

1.5 General safety instructions . . . . . 2

1.6 Warning about misuse . . . . . 2

1.7 Exclusion of liability . . . . . 2

**2 Product description**

2.1 Purpose . . . . . 2

2.2 Determination and use for explosion protection . . . . . 2

2.3 Ordering code . . . . . 2

2.4 Special versions . . . . . 2

2.5 Included in delivery . . . . . 2

2.6 Technical Data . . . . . 3

2.7 Response time (reaction time) . . . . . 3

2.8 Safety classification . . . . . 4

2.9 Functions . . . . . 4

2.9.1 Protective mode / Automatic . . . . . 4

2.9.2 Restart Interlock (operation) . . . . . 4

2.9.3 Restart interlock with double acknowledgement/reset . . . . . 4

2.9.4 Fixed blanking (EX-SLC440) . . . . . 5

2.9.5 Fixed blanking with movable edge region (EX-SLC440) . . . . . 5

2.9.6 Blanking of moving objects (EX-SLC440) . . . . . 5

2.9.7 Blanking of moving objects (SLG440) . . . . . 6

2.9.8 Contactor control (EDM) . . . . . 6

2.9.9 Rotating the display by 180 degrees . . . . . 7

2.10 Self-test . . . . . 7

2.11 Beam coding A . . . . . 7

**3 Parameterisation**

**4 Mounting**

4.1 General conditions . . . . . 9

4.2 Protection field and approach . . . . . 9

4.3 Setting mode . . . . . 9

4.4 Safety distance . . . . . 10

4.5 Increasing the safety distance in the event of risk of a protection field overlap . . . . . 11

4.5.1 Minimum distance to reflecting surfaces . . . . . 12

4.6 Dimensions emitter and receiver EX-SLC/SLG440 . . . . . 13

4.6.1 Dimensions emitter and receiver EX-SLC440 . . . . . 13

4.6.2 Dimensions emitter and receiver EX-SLG440 . . . . . 13

4.6.3 Mounting set . . . . . 13

**5 Electrical connection**

5.1 General information for electrical connection . . . . . 13

5.2 Wiring diagram . . . . . 14

5.3 Wiring example . . . . . 14

5.4 Connector configuration Receiver, Emitter & Cable . . . . . 14

**6 Set-up and maintenance**

6.1 Check before start-up . . . . . 15

6.2 Maintenance . . . . . 15

6.3 Regular check . . . . . 15

6.4 Half-yearly inspection . . . . . 15

6.5 Cleaning . . . . . 15

**7 Diagnostic**

7.1 Status information LED . . . . . 16

7.2 Fault diagnostic . . . . . 17

**8 Disassembly and disposal**

8.1 Disassembly . . . . . 17

8.2 Disposal . . . . . 17

**9 Appendix**

9.1 Contact . . . . . 17

**10 EU Declaration of conformity**

**1. About this document**

**1.1 Function**

This operating instructions manual provides all the information you need for the mounting, set-up and commissioning to ensure the safe operation and disassembly of the safety switchgear. The operating instructions must be available in a legible condition and a complete version in the vicinity of the device.

**1.2 Target group: authorised qualified personnel**

All operations described in this operating instructions manual must be carried out by trained specialist personnel, authorised by the plant operator only.

Please make sure that you have read and understood these operating instructions and that you know all applicable legislations regarding occupational safety and accident prevention prior to installation and putting the component into operation.

The machine builder must carefully select the harmonised standards to be complied with as well as other technical specifications for the selection, mounting and integration of the components.

**1.3 Explanation of the symbols used**



**Information, hint, note:**

This symbol indicates useful additional information.



**Caution:** Failure to comply with this warning notice could lead to failures or malfunctions.

**Warning:** Failure to comply with this warning notice could lead to physical injury and/or damage to the machine.

**1.4 Appropriate use**

The Schmersal range of products is not intended for private consumers.

The products described in these operating instructions are developed to execute safety-related functions as part of an entire plant or machine. It is the responsibility of the manufacturer of a machine or plant to ensure the correct functionality of the entire machine or plant.

The safety switchgear must be exclusively used in accordance with the versions listed below or for the applications authorised by the manufacturer. Detailed information regarding the range of applications can be found in the chapter "Product description".

**1.5 General safety instructions**

The user must observe the safety instructions in this operating instructions manual, the country specific installation standards as well as all prevailing safety regulations and accident prevention rules.



Further technical information can be found in the Schmersal catalogues or in the online catalogue on the Internet: [products.schmersal.com](http://products.schmersal.com).

The information contained in this operating instructions manual is provided without liability and is subject to technical modifications.

There are no residual risks, provided that the safety instructions as well as the instructions regarding mounting, commissioning, operation and maintenance are observed.

Additional measures could be required to ensure that the system does not present a dangerous breakdown, when other forms of light beams are available in a special application (e.g. use of wireless control devices on cranes, radiation of welding sparks or effects of stroboscopic lights).

**1.6 Warning about misuse**



In case of improper use or manipulation of the safety switchgear, personal hazards or damages to machinery or plant components cannot be excluded. The relevant requirements of the standards ISO 13855 and ISO 13857 must be observed.



Only if the information described in this operating instructions manual are realised correctly, the safety function and therefore the compliance with the Machinery Directive is maintained.

**1.7 Exclusion of liability**

We shall accept no liability for damages and malfunctions resulting from defective mounting or failure to comply with this operating instructions manual. The manufacturer shall accept no liability for damages resulting from the use of unauthorised spare parts or accessories.

For safety reasons, invasive work on the device as well as arbitrary repairs, conversions and modifications to the device are strictly forbidden, the manufacturer shall accept no liability for damages resulting from such invasive work, arbitrary repairs, conversions and/or modifications to the device.

**2. Product description**

**2.1 Purpose**

The EX-SLC/SLG440 is a non-contact, self-testing safety guard (AOPD), which is used for the protection of hazardous points, hazardous areas and machine accesses. If one or more light beams are interrupted, the hazardous movement must be stopped.



The user must evaluate and design the safety chain in accordance with the relevant standards and the required safety level.



The entire concept of the control system, in which the safety component is integrated, must be validated to the relevant standards.

**2.2 Determination and use for explosion protection**

The EX-SLC/SLG440 series can be installed in potentially explosive gas and dust atmospheres of Zones 1/21 and 2/22, category 2GD. The safety switchgear may only be operated in the temperature range specified in the datasheet. External influences, e.g. solar radiation, external sources of cold, must be borne in mind and precautionary measures taken, if applicable.

The installation and maintenance requirements to the standard series 60079 must be met.

The safety-technical data and features according to the applicable test certificate (or possible other approvals) are mentioned in the technical data.

**2.3 Ordering code**

This operating instructions manual applies to the following types:

**EX-SLC440-ER-①-②-③**

No.	Option	Description
①	xxxx	Protected heights in mm available lengths: 0330, 0490, 0650, 0810, 0970, 1130, 1370
②	14	Resolution 14 mm
	30	Resolution 30 mm
③		Range 0.3 ... 7 m for resolution 14 mm
		Range 0.3 ... 10 m for resolution 30 mm
H		High range 3 ... 10 m for resolution 14 mm
		High range 4 ... 20 m for resolution 30 mm

**EX-SLG440-ER-①-②**

No.	Option	Description
①	0500-02	Distance between outermost beams: 500 mm, 2 beams
	0800-03	800 mm, 3 beams
	0900-04	900 mm, 4 beams
②		Range 0.3 ... 12 m
	H	High range 4 ... 20 m

**2.4 Special versions**

For special versions, which are not listed in the ordering code, these specifications apply accordingly, provided that they correspond to the standard version.

**2.5 Included in delivery**

- Emitter E, Receiver R in protective enclosure
- 4 mounting sets
- 2 Ex cable glands and 4 Ex locking screws
- Operating instructions DE/EN

**2.6 Technical Data**

Marking in accordance with the ATEX Directive:	⊕ II 2G ⊕ II 2D
Marking in accordance with standards:	Ex db op is IIA T6 Gb Ex op is tb IIIC T80°C Db
Applied standards:	EN 61496-1, EN 61496-2, ISO 13849-1, EN 62061, EN IEC 60079-0, EN 60079-1, EN 60079-28, EN 60079-31
Certificate numbers:	TÜV CY 22 ATEX 0206673 X
- ATEX:	
Material of the housings:	Shatterproof glass
Max. Impact energy:	7 J
- Glass housing:	2 J
Protection field heights:	
- EX-SLC440	330 mm ... 1370 mm
- EX-SLG440	500 mm, 800 mm, 900 mm
Detection ability for test bodies:	
- EX-SLC440	14 mm and 30 mm
- EX-SLG440	2 beams with resolution 500 mm <sup>3)</sup> 3 beams with resolution 400 mm <sup>3)</sup> 4 beams with resolution 300 mm <sup>3)</sup>
Range of the protection field:	
EX-SLC440, Resolution 14 mm:	
- Standard	0.3 ... 7 m
- High range	3 ... 10 m
EX-SLC440, Resolution 30 mm:	
- Standard	0.3 ... 10 m
- High range	4 ... 20 m
EX-SLG440:	
- Standard	0.3 ... 12 m
- High range	4 ... 20 m
Response time:	
- beam coding (normal)	1 ... 48 beams = 10 ms 49 ... 144 beams = 20 ms
- beam coding A	1 ... 48 beams = 15 ms 49 ... 144 beams = 27 ms
Rated operating voltage:	24 VDC ±10% (PELV) supply unit $I_{max}$ 2.0 A, to EN 60204 (power drop ≤ 20 ms)
Rated operating current:	
- Emitter:	max. 200 mA
- Receiver:	max. 700 mA
Wavelength of the IR radiation:	
- EX-SLC	850 nm
- EX-SLG	880 nm
<b>Emitter, infrared emitted radiation</b>	
- to DIN EN 12198-1:	Category 0
- to DIN EN 62471:	free group
<b>Safety outputs</b>	
OSSD1, OSSD2:	2 x short-circuit proof PNP semi-conductor outputs
Test impulse cycle OSSD:	750 ms
Test impulse length:	100 µs
Switching voltage HIGH <sup>1)</sup> :	15 ... 26.4 V
Switching voltage LOW <sup>1)</sup> :	0 ... 2 V
Switching current each OSSD:	0 ... 250 mA
Leakage current <sup>2)</sup> :	1 mA
Load capacity:	0 ... 2.2 µF
Load inductance <sup>4)</sup> :	0 ... 2 H
Admissible conduction resistance between OSSD and load:	2.5 Ω
Admissible conduction resistance of the supply cable:	1.5 Ω
<b>Contact control (EDM)</b>	
Input voltage HIGH (inactive):	11 ... 30 V
Input voltage LOW (active):	0 ... 2.0 V
Input current HIGH:	3 ... 10 mA
Input current LOW:	0 ... 2 mA
<b>Input release restart interlock/restart interlock 2</b>	
Input voltage HIGH (active):	11 ... 30 V
Input voltage LOW (inactive):	0 ... 2.0 V
Input current HIGH:	3 ... 10 mA
Input current LOW:	0 ... 3 mA
Functions:	automatic mode, restart interlock, double reset, contactor control, beam blanking fixed and floating, beam coding A

**Signal times**

Contact control:	max. 500 ms
Restart interlock (manual reset):	50 ms ... 1.5 s, signal transmission in case of falling edge
LED indications emitter:	transmitting, status
LED indications receiver:	OSSD ON, OSSD OFF, restart, signal reception, blanking, information
Cable entries:	3 x M20
Connection:	Connector plug M12, Receiver 8-pole, Emitter 4-pole
Ambient temperature:	-20° C ... + 50° C; at -20° C: Reduction of range by -10%
Storage temperature:	-25° C ... + 70° C
Interface:	Diagnostics and function setting
Degree of protection:	IP66 to EN 60529
Version:	as of 2021 version 3.1

<sup>1)</sup> According to IEC 61131-2

<sup>2)</sup> In case of failure, the leakage current at the most flows to the OSSD cable. The downstream control element must recognise this state as LOW. A safety PLC must detect this state.

<sup>3)</sup> Resolution = beam distance + beam diameter 10 mm

<sup>4)</sup> The load induction generates an induced voltage during the switch-off, which compromises the downstream components (spark quenching element).

**2.7 Response time (reaction time)**

The response time depends on the height of the protection field, the resolution, the number of light beams and the beam coding A.

EX-SLC440 Resolution 14 mm				
Protection field height [mm]	Beams (Lines) [Number]	Response time [ms]	Response time with Beam coding A [ms]	Weight [kg]
330	32	10	15	4.6
490	48	10	15	4.9
650	64	20	27	6.3
810	80	20	27	6.6
970	96	20	27	6.8
1130	112	20	27	7.0
1370	136	20	27	8.4

EX-SLC440 Resolution 30 mm				
Protection field height [mm]	Beams (Lines) [Number]	Response time [ms]	Response time with Beam coding A [ms]	Weight [kg]
330	16	10	15	4.6
490	24	10	15	4.9
650	32	10	15	6.3
810	40	10	15	6.6
970	48	10	15	6.8
1130	56	20	27	7.0
1370	68	20	27	8.4

EX-SLG440				
Beams (Lines) [Number]	Beam distance [mm]	Response time [ms]	Response time with Beam coding A [ms]	Weight [kg]
2	500	10	15	4.9
3	400	10	15	6.55
4	300	10	15	6.7

### 2.8 Safety classification

Standards:	ISO 13849-1, EN 62061
PL:	up to e
Control Category:	4
PFH value:	$5.14 \times 10^{-9} / h$
SIL:	suitable for SIL 3 applications
Mission time:	20 years



If multiple safety components are wired in series, the Performance Level to ISO 13849-1 will be reduced due to the restricted error detection under certain circumstances.

### 2.9 Functions



All steps required to configure and parametrise the functions of the BWS may only be carried out outside of the potentially explosive areas and by authorised personnel.

The system consists of a receiver and an emitter. For the described functions, no further switching elements are required. The diagnostic and function selection takes place with a command device (key release), refer to the chapter on parameterisation.

The system has the following features:

- Protective mode automatic (automatic start after release of the protection zone)
- Restart Interlock (manual reset)
- Double acknowledgement/reset
- Contactor control (EDM)
- Beam coding A
- Blanking of fixed protection field areas
- Blanking of fixed protection field areas with movable edge region
- Blanking of movable protection field areas

#### Factory setting

The system features many functions without needing any additional devices. The following table gives an overview of the possible functions and the factory settings configuration.

Function	Factory setting	Configuration
Protective mode, automatic	not active	External wiring
Restart interlock (manual reset)	not active	External wiring
Double acknowledgement/reset	not active	with command device
Blanking fixed/floating	not active	with command device
Contactor control (EDM)	not active	with command device
Beam coding A	not active	with command device




By default neither the restart interlock (manual reset) nor the protective mode is active. One of both operating modes must be wired in order to enable the OSSD outputs. If no operating mode is selected, the following message is shown: **Status indication E1 + LED OSSD OFF (red)**

#### 2.9.1 Protective mode / Automatic

The protective mode switches the OSSD outputs to the ON state (protection field not interrupted), without external release of a switching device.

#### Wiring of the receiver

Jumper connection pin 1 with pin 6



This operating mode generates an automatic restart of the machine if the protection field is not interrupted.



A 24 VDC High-signal at the input of pin 1 leads to a restart of the system. If the 24 VDC High-signal is still present at pin 1 after the self-test, the system switches to setting mode, see chapter "Setting mode".




This operating mode may only be chosen in conjunction with the restart interlock (manual reset) of the machine. This operating mode must not be chosen, if persons may step behind the protection field.

#### 2.9.2 Restart Interlock (operation)

The restart interlock (manual reset) prevents an automatic enabling of the outputs (OSSDs ON state) after switch-on of the operating voltage or an interruption of the protection field. The system switches the outputs only to ON state, when an external command device (restart button) generates an enabling signal at the restart input (receiver).

#### Wiring of the receiver

- Jumper connection pin 5 with pin 6
- Command device (enabling button) at pin 1



The command devices (enabling button) must be installed outside of the hazardous area. The operator must have a clear view to the hazardous area when actuating the enabling button.


#### 2.9.3 Restart interlock with double acknowledgement/reset

In applications with access monitoring, a complete overview of the hazardous areas is often not possible; despite that, a reset of the command device for the restart interlock outside of the hazardous area by third parties is enabled at all times, although possible persons/operators are in the non visible area. This hazardous situation is avoided by means of a double reset, i.e. integration of two command devices inside and outside the hazardous area.



**Wiring of the receiver**

- Command device S1 at pin 1
- Command device S2 at pin 5
- Pin 6, no signal (input open)



**Specification**

The operating mode is available, when the parameter setting - double reset is activated (P 5). See chapter Parameter setting.

**Sequence for enabling:**

- 1) Actuate command device inside of the hazardous area (S2) and leave the hazardous area
- 2) Go through protected field or interrupt at least one beam, then release protected field
- 3) Actuate the command device outside of the hazardous area (S1)

Command device S1 can be reset (acknowledged) within a time frame of 2 to 60 seconds after the actuation of S2. If the order or the time requirement is not respected, the process must be repeated. If the order or the time requirement is not followed, the process must be repeated.

**Signalling: LED restart (yellow)**

Status	Comments
ON	Release of S2 (restart interlock 2) waiting for signal
flashing	Release of S1 (restart interlock) waiting for signal




If double acknowledgement is used, neither bridge 1 nor bridge 2 is set.

**2.9.4 Fixed blanking (EX-SLC440)**

The EX-SLC440 can blank stationary objects in the protection field.

Multiple protection field areas can be blanked. If small changes are made within the fixed blanking area, each time 1 beam can be additionally blanked to increase the tolerance. See chapter Parameter setting - Fixed blanking with movable edge regions (P 2).



**Key**

	Object in protection field
	mechanical cover

The range of the fixed blanking can be arbitrarily chosen in the protection field.

The first beam line, which realises the optical synchronisation and is located immediately behind the diagnostic window, cannot be blanked.

The area of the fixed blanking must not be modified after the teach-in process. Any change of the area or removal of the object from the protection field will be detected by the system. As a result, the outputs are disabled (locked). This locking can be neutralised by executing a new teach-in process in accordance with the actual beam interruptions.



The function is activated by means of the parameter setting (P1). If the function is activated, the LED blanking in the diagnostic window of the receiver starts flashing. See chapter Parameter settings.



- The remaining lateral areas must be protected against intrusion by means of mechanical covers.
- The lateral covers must be fixed with the object.
- Partial covers are not authorised.
- After the fixed blanking, the protection field must be tested by means of the test rod.
- The restart interlock function of the safety light curtain or the machine must be activated.

**2.9.5 Fixed blanking with movable edge region (EX-SLC440)**

This function can compensate slight position changes of one to two fixed blanked objects with a change of  $\pm 1$  beam. This position change corresponds to an amplitude of approx.  $\pm 10$  mm resolution 14 mm and approx.  $\pm 20$  mm resolution 30 mm upwards and downwards in the protection field.

**Example of beam blanking (object in protection field)**

Beam number	3	4	5	6	7	Status OSSDs
Fixed blanking, beam 4, 5 and 6	○	●	●	●	○	Teach In
Shift 1 beam down	●	●	●	○	○	ok
Shift 1 beam up	○	○	●	●	●	ok
Object only covers 2 beams	○	○	●	●	○	ok
Object only covers 2 beams	○	●	●	○	○	ok
Object with downward edge displacement	●	●	●	●	○	ok
Object with upward edge displacement	○	●	●	●	●	ok
Object displacement exceeds 1 beam	○	○	○	●	●	Error
Object size changed (1 beam)	○	○	●	○	○	Error
Object size changed (5 beams)	●	●	●	●	●	Error

The operating mode is only available, when the parameter setting - fixed blanking with movable edge region is activated (P 2). See chapter Parameter setting.

A combination with only fixed beam blanking (P 1) or additional floating beam blanking (P 3) is not possible.

This blanking changes the physical resolution. The effective resolution of the EX-SLC440 can be found in the table in the chapter "Floating blanking" (1 beam).



Perform a new calculation of the safety distance with the effective resolution. Adjust the safety distance in accordance with your calculation.


**2.9.6 Blanking of moving objects (EX-SLC440)**

The EX-SLC440 safety light curtain can blank movable objects in the protection field.

The EX-SLC440 can be used for the floating blanking of 2 beams in the protection field, refer to parameter setting (P 3). A combination of fixed and floating beam blanking (P 1 and P 3) is enabled.

A combination of fixed blanking with movable edge region (P 2) and floating blanking (P 3) is not possible.

**Example**  
Floating and fixed blanking



**Key**  
1: Fixed blanking area  
2: Floating blanking area

The function enables an arbitrary floating blanking of partial areas in the protection field. The first beam, which is located immediately behind the diagnostic window, cannot be blanked.

This function allows an interruption of the protection field without the outputs being disabled in case of material movement in the protection field. material ejection or process-controlled material movement without the outputs being disabled in case of material movement in the protection field. With this extension of the object detection the resolution is increased. Therefore the physical resolution is changed to an effective resolution. This effective resolution must be used to calculate the safety distance. Use formula (1) in the chapter "Safety distance" to calculate the safety distance with the effective resolution if a maximum of 2 light beams are blanked.

The number of light beams to be blanked is limited, see table "Effective resolution".

A system with a physical resolution of 14 mm will have an increased effective resolution of 34 mm in case of floating blanking of two beams. The effective resolution must be permanently and clearly visible labelled at the receiver.

**Effective resolution**

The effective resolution in case of activated blanking can be found in the following table.

Resolution 14 mm		
Blanked beams	Physical resolution	Effective resolution
1	14	24
2	14	34

Resolution 30 mm		
Blanked beams	Physical resolution	Effective resolution
1	30	48
2	30	68


The function is activated in parameter setting mode (P 3). If the function is activated, the LED blanking in the diagnostic window of the receiver starts flashing.

Perform a new calculation of the safety distance with the effective resolution. Adjust the safety distance in accordance with your calculation.

The standard IEC/TS 62046 includes information, which describe possibly required additional measures to prevent a person from reaching a hazard through the blanking areas of a protection field.

**2.9.7 Blanking of moving objects (SLG440)**

The EX-SLG440 can blank movable objects in the protection field.



The floating blanking range is authorised for individual beams in case of obstacles, taking the protective function into account.

The function enables an arbitrary floating blanking of partial areas in the protection field. The first beam, which is located immediately behind the diagnostic window, cannot be blanked.

This function allows for an interruption of maximum 1 light beam without the outputs being disabled in case of material movement in the protection field, e.g. ejection of material or process-controlled material movement.

The operating mode is only available, when the parameter setting P 3 is activated. See chapter Parameter setting.



- The variable blanking of one beam is not authorised with the 2-beam EX-SLG440.
- The blanking of one beam at the most in the EX-SLG440 3-beam version or the EX-SLG440 4-beam version is authorised, provided that the protective function is taken into account.
- The restart interlock (manual reset) function of the safety light grid or the machine must be activated.
- The protection field must be checked by a qualified person after the configuration.
- The standard EN 62046 includes information, which describes possible required additional measures to prevent a person from reaching a hazard through the beam blanking of a protection field.

**2.9.8 Contactor control (EDM)**

The contactor control monitors the controlled switching elements (auxiliary contacts of the contactors) of both outputs. This monitoring is realised after each interruption of the protection field and prior to the restart (enabling) of the outputs. In this way, malfunctions of the contactors are detected, e.g. contact welding or contact spring breakage. If the light curtain detects a malfunction of the switching elements, the outputs are locked.

After elimination of the error, a power reset is required.




The contactor control is not activated upon delivery. The function is activated in parameter setting mode (P 4).

**Connection EDM**

**Wiring of the receiver**


- Kn1, Kn2 = auxiliary contact of the last switching relay



The auxiliary contacts must only be connected, when the function is activated!

### 2.9.9 Rotating the display by 180 degrees

The orientation of the 7 segment display can be rotated by 180 degrees via the software option. This ensures that the display remains readable in rotated mounting position of the AOPD.



Parameter **P 7 -**  
Display normal orientation



Parameter **P 7 A**  
Display rotated

### 2.10 Self-test


The system performs a complete self-test and safety test within 2 seconds after the operating voltage has been switched on. If the protection field is free, the system switches to the ON condition (automatic mode). In case of an error, the outputs at the receiver do not switch to the ON state. An error message is emitted in the form of an error code. For more information, refer to chapter Fault diagnosis.

During operation, the system executes a cyclic self-test. Safety-relevant faults are detected within the reaction time and cause the outputs to be switched off and an error code to be emitted.


### 2.11 Beam coding A

The preset beam coding of the safety light curtain must be adjusted, when systems operating in each other's vicinity and a set-up as shown in the image below (no interference) is impossible. When supplied, the beam coding A is **not active**. A receiver with activated beam coding A can distinguish the beams of the emitter with the same beam coding, which are destined to this particular receiver, from foreign beams.

If adjacent systems are operated without beam coding A, the user is at risk.



No interference




Interference:  
beam coding A required!

- The beam coding A avoids mutual interference of adjacent systems.
- The beam coding A is permanently shown by the emitter and the receiver by means of flashing LED's (refer to LED status information).
- The beam coding A must be set for **each sensor** (receiver and emitter) individually.
- The function at the receiver is activated in parameter setting mode (P 6).

### Emitter parameter setting

#### Wiring of the emitter

- Jumper connection pin 1 with pin 2
- Jumper connection pin 3 with pin 4



The response time of the system is increased when beam coding A is used. To this end, the safety distance must be adjusted. Refer to chapter: Response time.

## 3. Parameterisation

The parameter setting of the EX-SLC440/EX-SLG440 enables the individual adjustment of the desired functionality to the application.

#### Adapter cable for parameter setting

Article No.	Designation (description)	Length
101217615	KA-0974 (Y-distributor with command device)	1 m

#### Parameter display (7-segment display)

A = parameter active

- = parameter not active

S. = save the current configuration

C. = delete the current configuration, new configuration = factory setting

n = unavailable (unauthorised setting, refer to Parameter setting information)

d. = diagnostic/setting mode


#### Parameter selection

Selection, change and acceptance of the parameters by means of the command device pushbutton S1:

- Switch to parameter setting Px briefly press the button  
0.1 ... 1.5 s
- Change parameter setting Px press button  
2.5 ... 6 s
- Save S. / Factory setting C. press button  
2.5 ... 6 s

#### Procedure




- 1) For the parameter setting, the receiver must be isolated from the operating voltage. In de-energised condition, the following jumper connection and the pushbutton S1 must be connected.



#### Wiring of the receiver


- Jumper connection from DOUT (Pin 6) to EDM (Pin 8)
  - Connection of the command device pushbutton S1 (+24 VDC) on Pin 1 (restart interlock)
  - Possible jumper connections from Pin 5 to Pin 6 or Pin 1 to Pin 6 must be removed. If the EDM function was activated, the auxiliary contact of Pin 8 must be removed.
- 2) The receiver switches to parameter setting mode when the operating voltage is switched on.

Signalling of the switching condition as follows

	7- segment display
	LED OSSD ON (red) active
	LED OSSD OFF (green) active

Parameter setting

1) When S1 is briefly pressed, the display shows **repeatedly**



- 2) Select the desired parameter by means of command device S1 (briefly press the button)
- 3) Select the desired parameter by means of the command device (press the button for a long time)
  1. Push button (approx. 2.5 s) → - flashes (parameter not active)
  2. Enable button when → **A** static (parameter active)
- 4) Save the new configuration with the parameter Save **S.** (push the button for a long)
  1. Actuate button (approx. 2.5 s) → **S.** flashes
  2. Enable button when → **S.** static
  3. Automatic restart → "segment circulation" then **P** is displayed (saving operation successful)

If no restart takes place (**S.**), the saving operation has not been successful (i.e. the parameter changes have not been saved). The procedure 1 to 3 must be repeated.

All parameters can be reset to the factory setting using parameter **C.** (clear/delete).

- 1) Press the button (approx. 2.5 s) → **C.** flashes
- 2) Enable the button when → **C.** static
- 3) Automatic restart → "Segment circulation", then **P** is displayed (all parameters have been deleted)

Return to normal operating mode

1. Switch off the operating voltage at the receiver
2. Remove jumper connection at the receiver DOUT (Pin 6) and EDM (Pin 8).
3. Select the desired operating mode (jumper connections)
4. Switch operating voltage on

Table Parameter setting

No.	Parameter	Status	Comments
<b>P 1</b>	Fixed blanking	- = not active A = Active	Position active saves all interrupted beam through Teach-in mode
<b>P 2</b>	Fixed blanking with movable edge region	- = not active A = Active	Tolerance in edge region ± 1 beam - adjust safety distance!
<b>P 3</b>	Floating blanking 1 beam or 2 beams	- = not active 1 = 1 beam 2 = 2 beams	Blanking of max. 2 beams - adjust safety distance!
<b>P 4</b>	Contact control/ EDM	- = not active A = Active	The auxiliary (NC) contacts are monitored
<b>P 5</b>	Double acknowledgement with command device restart interlock N° 2	- = not active A = Active	Operating mode "Protective mode with double reset" restart n° 2"
<b>P 6</b>	Beam coding A (alternative)	- = not active A = Active	Activating upon mutual interference of identical systems
<b>P 7</b>	Rotating the display by 180 degrees	- = not active A = Active	The orientation of the 7 segment display can be turned by 180 degrees
<b>S.</b>	Save	S.	Press button S1 to save changes (2.5 ... 6.0 s)
<b>C.</b>	Clear/delete	C.	Press button S1 to save factory settings (2.5 ... 6.0 s)
<b>d.</b>	Diagnostic/ setting mode	d.	Switch to setting mode



P 1 or P 2 - - When fixed blanking is activated, all beams which are interrupted in the protection field at the time that command device S1 is actuated (> 2.5 sec. with falling edge) are blanked.  
P 2 - Parameter combination P 1 and P 2 or P 2 and P 3 is not authorised. Status indication n = not available  
P 6 - Beam coding A must also be set at the emitter, refer to chapter Beam coding A



**4. Mounting**

**4.1 General conditions**

The following guidelines are provided as preventive warning notices to ensure a safe and appropriate handling. These guidelines are an essential part of the safety instructions and therefore must always be observed and respected.




- The enclosure must be installed only in areas which are considered to be at a low risk of impact.
- The AOPD must not be used on machines which cannot be stopped electrically in case of emergency.
- The safety distance between the AOPD and a hazardous machine movement must always be observed.
- Additional mechanical safety guards must be installed so that the operator has to pass through the protection field to reach the hazardous machine parts.
- The AOPD must be installed so that the personnel always must be within the detection zone when operating the machine. An incorrect installation can lead to serious injuries.
- Never connect the outputs to +24VDC. If the outputs are wired to +24VDC, they are in ON state, as a result of which they are unable to stop a hazardous situation occurring on the application/machine.
- The safety inspections must be conducted regularly.
- The connecting cables must be connected in accordance with the installation instructions.
- The fixing screws of the mounting brackets must be firmly tightened.


**4.2 Protection field and approach**

The protection field of the AOPD consists of the area between the protection field markings of emitter and receiver. Additional protective devices must ensure that the operator has to pass through the protection field to reach the hazardous machine parts. The EX-SLC must be installed so that personnel are always located within the detection zone of the safety device when operating the hazardous machine parts to be secure.

**Correct installation**




Hazardous machine parts can only be reached after passing through the protection field.




The presence of staff members between the protection field and hazardous machine parts must be prevented/avoided (protection against stepping over).

**Unauthorised installation**



Hazardous machine parts can be reached without passing through the protection field.



The presence of staff members between the protection field and hazardous machine parts is possible.

**Alignment of the sensors**

**Procedure:**

1. Emitter and receiver must be fitted parallel to each other and at the same height.
2. Choose the operating mode "Automatic" (see chapter Protective mode/automatic) and switch the operating voltage on.
3. The 7-segment display in the receiver shows the current signal quality/fine setting (signalling, see chapter "set-up mode") for 5 minutes.  
 At first rotate the emitter and then the receiver towards each other until you have the best possible signal strength of 3 horizontal bars (7 segment display) (note that 2 horizontal bars is sufficient). Fix this position using the screws to the mounting angle.  
 If set-up is not possible, switch to set-up mode (see chapter "set-up mode").  
 The set-up mode leads to the best possible positioning of the sensors through the basic setting (position of the second and last beam) and the optimisation with the fine adjustment (total signal).

**Status indication of the LED**

OSSD ON (green) is active, signal strength (orange) is not active.

**4.3 Setting mode**



**Setting tool with 7-segment display**

The function supports the best possible alignment between emitter and receiver. The indication shows the signal strength of the different receivers while the safety outputs are switched off. For the optical indication of the signal strength two areas are available, the signal strength of the second and the last beam in the protection zone (default setting) as well as the best possible orientation of all beams (fine adjustment).


**Activating setting mode**

After the system start, a signal impulse (High signal 24 VDC) must be present at the input restart interlock (pin 1) of the receiver for at least 2.0 s (pushbutton/enabling).  
 The 7 segment display starts with the default setting (vertical bar).  
 The sensors are aligned in parallel and at the same height until both segments have reached a signal strength of 50% to 100%.




With a signal impulse on the input release (pin 1) you can change between default setting and fine adjustment as long as the signal strength is at 50% of the default setting (vertical bar).  
 After setting the sensors, set-up mode can be terminated by the presence of a HI-signal at pin 1 for at least 2.5 seconds (max. 6 seconds) and actuation of the enabling button or by a receiver system start-up (+UB OFF/ON).

Orientation / Alignment

Receiver not parallel



Both sensors parallel




Beam (a) = receive signal OK  
Beam (b) = no receive signal

Beam (a) and beam (b)  
= receive signals OK


Indication basic setting

The signal strength is displayed per beam with two segments for the 2nd (a) and the last (b) beam.



Indication fine adjustment

The fine adjustment is displayed by means of up to 3 segments (crossbars) for the best possible signal strength of all beams.



The availability of the system is also assured if due to soiling or operation at nominal range the best possible signal strength (3 segments) is not reached.

4.4 Safety distance

The safety distance is the minimum distance between the protection field of the safety light curtain and the hazardous area. The safety distance must be observed to ensure that the hazardous area cannot be reached before the hazardous movement has come to standstill.

The safety distance between the safety light curtain / light grid and the hazardous point must always be respected and observed. If a person reaches the hazardous point before the hazardous movement has come to a standstill, he or she is exposed to serious injuries.

To calculate the minimum distances of the safety guards with regard to the hazardous point, ISO 13855 and ISO 13857 must be observed.

Calculation of the safety distance according to ISO 13855 and ISO 13857

The safety distance depends on the following elements:

- Stopping time of the machine (calculation by run-on time measurement)
- Response time of the machine and the safety light curtain and the downstream relay (entire safety guard)
- Approach speed
- Resolution of the safety light curtain

Calculation of the safety distance for safety light curtains EX-SLC440

The safety distance for resolutions 14 mm up to 40 mm is calculated by means of the following formula:

$$(1) S = 2000 \text{ mm/s} * T + 8 (d - 14) [\text{mm}]$$

S = Safety distance [mm]

T = Total reaction time (machine run-on time, reaction time of the safety guard, relays, etc.)

K = Approach speed

d = Resolution of the safety light curtain

The approach speed is covered with a value of 2000 mm/s

If value  $S \leq 500$  mm after the calculation of the safety distance, then use this value.

If value  $S \geq 500$  mm, recalculate the distance:

$$(2) S = 1600 \text{ mm/s} * T + 8 (d - 14) \text{ [mm]}$$

If the new value  $S > 500$  mm, use this value as safety distance.  
 If the new value  $S < 500$  mm, use a minimum distance of 500 mm.

**Example**


Response time of the safety light curtain = 10 ms  
 Resolution of the safety light curtain = 14 mm  
 Stopping time of the machine = 330 ms

$$S = 2000 \text{ mm/s} * (330 \text{ ms} + 10 \text{ ms}) + 8(14 \text{ mm} - 14 \text{ mm})$$

$$S = 680 \text{ mm}$$

$$S \geq 500 \text{ mm, therefore new calculation with } K = 1600 \text{ mm/s}$$

$$S = 544 \text{ mm}$$



**Calculation of the safety distance**  
**Multi-beam light grid EX-SLG440**

$$S = (1600 \text{ mm/s} * T) + 850 \text{ mm}$$

S = Safety distance [mm]  
 T = Total reaction time (machine run-on time, reaction time of the safety guard, relays, etc.)  
 K = Approach speed 1600 mm/s  
 C = Safety supplement 850 mm

**Example**

Response time of the EX-SLG440 = 10 ms  
 Stopping time of the machine T = 170 ms


$$S = 1600 \text{ mm/s} * (170 \text{ ms} + 10 \text{ ms}) + 850 \text{ mm}$$

$$S = 1138 \text{ mm}$$

The following mounting heights must be observed:

Number of beams	Mounting height above reference floor in mm
2	400, 900
3	300, 700, 1100
4	300, 600, 900, 1200

**Safety distance to the hazardous area**



The formulas and calculation examples are related to the vertical set-up (refer to drawing) of the safety light grid with regard to the hazardous point. Please observe the applicable harmonised EN standards and possible applicable national regulations.

**4.5 Increasing the safety distance in the event of risk of a protection field overlap**


**!** If an overlap of the protection field is possible, take care with the calculation of the safety distance referring to additional  $C_{RO}$  according to the table A1 as per norm ISO 13855.

The norm ISO 13855 defines two types of safety distances,  
 - Access **through** the protection area with an additional distance C, according to the resolution of the AOPD  
 - Access **over** the protection area with an additional distance  $C_{RO}$  according to table 1

If it is possible to reach through the hazardous area (vertical alignment) then both values C and  $C_{RO}$  have to be determined. The higher value of both is to be used for calculating the safety distance. Calculating the safety distance with  $C_{RO}$ :

$$S_{CRO} = K * T + C_{RO}$$

K = Approach speed  
 T = Total response time (machine run-on time, response time of the safety guard, relays, etc.)  
 $C_{RO}$  = Additional distance due to protection field overlap to the hazardous area with part(s) of body.



- 1 Safety sensor
- 2 Hazardous point
- 3 Floor
- a Height of the hazardous point
- b Height of the upper edge of the protection area of the AOPD

Reaching through the protective area of a non-contact functioning guard system (extract ISO 13855)

Height of the hazardous point a [mm]	Height b of the upper edge of the protection area of the non-contact functioning guard system											
	900	1000	1100	1200	1300	1400	1600	1800	2000	2200	2400	2600
Additional distance C <sub>RO</sub> to the hazardous area [mm]												
2600	0	0	0	0	0	0	0	0	0	0	0	0
2500	400	400	350	300	300	300	300	300	250	150	100	0
2400	550	550	550	500	450	450	400	400	300	250	100	0
2200	800	750	750	700	650	650	600	550	400	250	0	0
2000	950	950	850	850	800	750	700	550	400	0	0	0
1800	1100	1100	950	950	850	800	750	550	0	0	0	0
1600	1150	1150	1100	1000	900	850	750	450	0	0	0	0
1400	1200	1200	1100	1000	900	850	650	0	0	0	0	0
1200	1200	1200	1100	1000	85	800	0	0	0	0	0	0
1000	1200	1150	1050	950	750	700	0	0	0	0	0	0
800	1150	1050	950	800	500	450	0	0	0	0	0	0
600	1050	950	750	550	0	0	0	0	0	0	0	0
400	900	700	0	0	0	0	0	0	0	0	0	0
200	600	0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0	0	0


**Determination of the additional distance C<sub>RO</sub> from the table:**

- 1) Locate the height of the upper edge of the hazardous area **a** (left table column)
- 2) Locate the height of the protection area **b** (upper table row)
- 3) C<sub>RO</sub> is to be taken from the crossing point of both axes


If the known value for **a** and **b** is between the table values, the next higher value is to be used.

**4.5.1 Minimum distance to reflecting surfaces**

During the installation, the effects of reflecting surfaces must be taken into account. In case of an incorrect installation, interruptions of the protection field could possibly not be detected, which could lead to serious injuries. The hereafter-specified minimum distances with regard to reflecting surfaces (metal walls, floors, ceilings or parts) must be imperatively observed.



**Safety distance a**



Calculate the minimum distance to reflecting surfaces as a function of the distance with an aperture angle of  $\pm 2.5^\circ$  degrees or use the value from the table below:


Distance between emitter and receiver [m]	Minimum distance a [mm]
0.2 ... 3.0	130
4	175
5	220
7	310
10	440
12	530

**Formula:  $a = \tan 2.5^\circ \times L$  [mm]**

a = Minimum distance to reflecting surfaces  
L = Distance between emitter and receiver

4.6 Dimensions emitter and receiver EX-SLC/SLG440

All measurements in mm.




4.6.1 Dimensions emitter and receiver EX-SLC440

Type	Protection field height ± 1 [mm]	Resolution [mm]	A Mounting dimension [mm]	B Height + 1 [mm]
EX-SLC440-ER-0330-14(-H)	330	14	573	716
EX-SLC440-ER-0330-30(-H)	330	30	573	716
EX-SLC440-ER-0490-14(-H)	490	14	573	716
EX-SLC440-ER-0490-30(-H)	490	30	573	716
EX-SLC440-ER-0650-14(-H)	650	14	1173	1316
EX-SLC440-ER-0650-30(-H)	650	30	1173	1316
EX-SLC440-ER-0810-14(-H)	810	14	1173	1316
EX-SLC440-ER-0810-30(-H)	810	30	1173	1316
EX-SLC440-ER-0970-14(-H)	970	14	1173	1316
EX-SLC440-ER-0970-30(-H)	970	30	1173	1316
EX-SLC440-ER-1130-14(-H)	1130	14	1173	1316
EX-SLC440-ER-1130-30(-H)	1130	30	1173	1316
EX-SLC440-ER-1370-14(-H)	1370	14	1473	1616
EX-SLC440-ER-1370-30(-H)	1370	30	1473	1616

4.6.2 Dimensions emitter and receiver EX-SLG440

Type	Protection field height ± 1 [mm]	Beams (lines) [Number]	Beam distance [mm]	A Mounting dimension [mm]	B Height + 1 [mm]
EX-SLG440-ER-0500-02(-H)	500	2	500	573	716
EX-SLG440-ER-0800-03(-H)	800	3	400	1173	1316
EX-SLG440-ER-0900-04(-H)	900	4	300	1173	1316

4.6.3 Mounting set



Alignment is via the mounting angle. Safety guard must not be opened

5. Electrical connection

5.1 General information for electrical connection



The electrical connection may only be carried out by authorised personnel in a de-energised condition.



Only use Ex cable glands and Ex locking screws with integrated or associated seals which are authorised for the corresponding field of application. The cable glands must be fitted in accordance with the applicable operating instructions manual. Cable glands are only authorised for permanent cables. The constructor must provide for the necessary strain relief. Unused cable entries must be sealed by means of Ex approved locking screws.



Always use the cable gland in accordance with the requisite conductor.


Steps for repairing the electrical connection for transmitter and receiver:

1. Release the cover screws from the connection cap and remove the cover.
2. Connect the connecting cable to the BWS and guide the cable end out through the cable gland.
3. Unused cable entries must be sealed by means of Ex locking screws.
4. Fit the cover of the connection cap (tightening torque 25 Nm).



Connection to the external potential equalisation terminal must be carried out in accordance with EN 60079-14 section 6.3. A ring cable lug of size M4 must be used for connection of the wire.

5.2 Wiring diagram



**Restart interlock (manual reset) (bridge 1)**

By bridging restart 2 (pin 5) and DOUT (pin 6), the restart interlock (manual reset) is activated. **Connect S1.**

**Protective mode / Automatic active (bridge 2)**

By bridging DOUT (Pin 6) and enable restart (Pin1), the protective mode is activated. **Don't connect S1.**


K1, K2 Relay for processing the switching outputs OSSD 1, OSSD 2

Kn1, Kn2 Auxiliary contacts of the last switching relay (optional) signals at input EDM (Pin 8)

**Only to be connected when the contactor control is activated.**

S1 Pushbutton for restart (optional)

5.3 Wiring example




**Safety relay module SRB-E-301MC (not included in delivery)**

- Contactor control KA and KB at X1/X2
- Command device  $\text{\textcircled{R}}$  Restart interlock restart at X1/X2
- OSSD outputs at S12 and S22
- QS-switch = nQS, deactivate cross-wire short detection

5.4 Connector configuration Receiver, Emitter & Cable

**RECEIVER**


**M12, 8-pole**



Designation	Description
1	Release/restart interlock
2	24 VDC
3	OSSD 1
4	OSSD 2
5	Restart 2
6	DOUT
7	0 VDC
8	Contactor control

**EMITTER**

**M12, 4-pole**



Designation	Description
1	24 VDC
2	COD 1
3	0 VDC
4	COD 2



Connect COD 1 / COD 2 only when beam coding A is activated!

## 6. Set-up and maintenance

### 6.1 Check before start-up

Prior to start-up, the following items must be checked by the responsible person.

#### Wiring connection check prior to start-up

1. A 24 V power adapter (see technical data) is required for the power supply. A power downtime of 20 ms must be bridged.
2. Presence of a voltage supply with correct polarity at the AOPD.
3. The connecting cable of the emitter is correctly connected to the emitter and the connecting cable of the receiver is correctly connected to the receiver.
4. The double insulation between the AOPD output and an external potential is assured.
5. The outputs OSSD1 and OSSD2 are not connected to +24 VDC.
6. The connected switching elements (load) are not connected to +24 VDC.
7. If two or more AOPDs are used within close range compared to each other, an alternating arrangement must be observed. Any mutual interference of the systems must be prevented.

#### Switch on the AOPD and check the operation in the following way

The AOPD performs a system test for approx. 2 seconds after the operating voltage has been switched on (indication through 7-segment display). After that, the outputs are enabled if the protection field is not interrupted. The LED "OSSD ON" at the receiver is on.



In case of incorrect functionality, please follow the instructions listed in the chapter Fault diagnostic.

### 6.2 Maintenance



Do not use the AOPD before the following inspection is terminated. An incorrect inspection can lead to serious and mortal injuries.

#### Conditions

For safety reasons, all inspection results must be archived. The operating principle of the AOPD and the machine must be known in order to be able to conduct an inspection. If the fitter, the planning technician and the operator are different persons, please make sure that the user has the necessary information at his disposal to be able to conduct the maintenance.

### 6.3 Regular check

A regular visual inspection and functional test, including the following steps, is to be performed:

1. The component does not have any visible damages.
2. The optics cover is not scratched or soiled.
3. Hazardous machinery parts can only be accessed by passing through the detection zone of the AOPD.
4. The staff remains within the detection area, when works are conducted on hazardous machinery parts.
5. The safety distance of the application exceeds the mathematically calculated one.

#### Operate the machine and check whether the hazardous movement stops under the hereafter mentioned circumstances.

1. Hazardous machine parts do not move when the protection field is interrupted.
2. The hazardous machine movement is immediately stopped, when the protection field is interrupted with the test rod directly at the emitter, directly at the receiver and in the middle between the emitter and the receiver.
3. There is no hazardous machine movement when the test rod is within the protection field.
4. The hazardous machine movement comes to standstill, when the voltage supply of the AOPD is switched off.

### 6.4 Half-yearly inspection

The following items must be checked every six months or if a machine setting is changed.

1. Machine stops or does not inhibit any safety function.
2. No machine modification or connection change, which affects the safety system, has taken place.
3. The outputs of the AOPD are correctly connected to the machine.
4. The total response time of the machine does not exceed the response time calculated during the first commissioning.
5. The cables, the connectors, the caps and the mounting angles are in perfect condition.

### 6.5 Cleaning


If the optics cover of the sensors is extremely soiled, the OSSD outputs may be disabled. Clean with a clean, soft cloth with low pressure.

The use of aggressive, abrasive or scratching cleaning agents, which could attack the surface, is prohibited.

## 7. Diagnostic

### 7.1 Status information LED

Receiver	Function	LED colour	Description
 <p>OSSD ON OSSD OFF Restart</p> <p>Signal reception Blanking Information</p>	OSSD ON	green	Safety outputs Signal condition ON
	OSSD OFF	red	Safety outputs Signal condition OFF
	Restart	Yellow	Input for command device
	Signal reception	orange	Evaluation of the signal reception
	Blanking	blue	Protection field(s) inactive (blanking)
	Information	yellow-green	Beam coding A

Emitter	Function	LED colour	Description
 <p>Information</p> <p>Emitting</p>	Information	green	Function display, Beam coding A
	Emitting	orange	Emitter active








Receiver LED	Status LED	Description
OSSD ON	ON	Protection field clear
OSSD OFF	ON	Protection field interrupted, system or configuration error
	ON	Error output refer to Fault diagnostic table
Restart	ON	Restart interlock (manual reset) active, signal expected at input restart interlock
Signal reception	ON/flashing	Signal reception too low, check alignment and installation height between emitter and receiver
		Cleaning the black profile cover
	OFF	Alignment between emitter and receiver OK, when the OSSD are enabled
Blanking	1 x flashing	Fixed blanking of the protection field(s)
	2 x flashing	Floating blanking, max. 1 beam
	3 x flashing	Floating blanking, 2 beams
	4 x flashing	Floating (max. 1 beam) and fixed blanking of protection field(s)
	5 x flashing	Floating (2 beams) and fixed blanking of protection field(s)
	6 x flashing	Fixed blanking with movable edge region
Information	flashing	Beam coding A is active

Emitter LED	Status LED	Description
Emitting	ON	Standard operation, emitter active
	flashing	Configuration error
Information	flashing	Beam coding A is active



**7.2 Fault diagnostic**

The light curtain performs an internal self-test after the operating voltage is switched on and the protection field is enabled. When a fault is detected, an error number e.g. E1 is displayed at the receiver. Each fault display is followed by a one-second delay.

Status display	Fault feature	Action
	Wiring erroroperating mode not defined (automatic or restart mode)	Check all connections at the receiver, Jumper connection 1 or jumper connection 2 present?
	Supply voltage	UB = 24V/DC ± 10%, check voltage source and primary voltage, note: after the fault message E2 has been displayed three times, a reset is executed.
	Error output (e), OSSD1 or OSSD2	Check the connections of both outputs, short-circuit of both OSSD, connection to level 0V or 24V, deactivate external (relay) cross-wire short monitoring
	Contactor control (EDM)	EDM active: check connections of both NC contacts, EDM not active: check level at Pin 8, open input
	Beam blanking	Check the blanking area(s) of fixed or floating objects with the selected parameter setting, fault elimination - repeat configuration in the parameter setting, possibly adjust P 1, P 2, P 3
	Configuration error in parameter setting	Check parameter setting and save/accept with "S." or delete/clear with "C." delete/clear
	System error	Restart the system, if E 7 display persists, exchange components

The error display is reset after elimination of the error cause and after the receiver has been switched back on. The error indication displays a 3-digit system error code for every 10th display.

**8. Disassembly and disposal**

**8.1 Disassembly**

The safety switchgear must be disassembled in a de-energised condition only.

**8.2 Disposal**

The safety switchgear must be disposed of in an appropriate manner in accordance with the national prescriptions and legislations.

**9. Appendix**



**9.1 Contact**

**Consultancy / Sales**

K. A. Schmersal GmbH & Co. KG  
 Möddinghofe 30  
 42279 Wuppertal  
 Germany  
 Phone: +49 202 6474-0  
 Fax: +49 202 6474-100

You will also find detailed information regarding our product variety on our website: [products.schmersal.com](http://products.schmersal.com)

10. EU Declaration of conformity

<b>EU Declaration of conformity</b>		
Original	K.A. Schmersal GmbH & Co. KG Möddinghofe 30 42279 Wuppertal Germany Internet: www.schmersal.com	
We hereby certify that the hereafter described components both in their basic design and construction conform to the applicable European Directives.		
<b>Name of the component:</b>	Series EX-SLC440 Series EX-SLG440	
<b>Type:</b>	see ordering code	
<b>Marking:</b>	⊕ II 2G Ex db op is IIA T6 Gb ⊕ II 2D Ex op is tb IIIC T80°C Db	
<b>Description of the component:</b>	Safety light curtain / safety light grid	
<b>Relevant Directives:</b>	Machinery Directive <sup>1)</sup> 2006/42/EC EMC-Directive 2014/30/EU Explosion Protection Directive (ATEX) <sup>2)</sup> 2014/34/EU RoHS-Directive 2011/65/EU	
<b>Applied standards:</b>	EN 61496-1:2013, EN 61496-2:2013, ISO 13849-1:2015, EN 62061:2005 + Cor.:2010 + A1:2013 + A2:2015, EN IEC 60079-0:2018, EN 60079-1:2014, EN 60079-28:2015, EN 60079-31:2014	
<b>Notified body, which approved the full quality assurance system, referred to in Appendix IV, 2014/34/EU:</b>	TÜV Rheinland Industrie Service GmbH Am Grauen Stein, 51105 Köln ID n°: 00 35	
<b>Notified body for the prototype test:</b>	<sup>1)</sup> TÜV NORD CERT GmbH Langemarckstr. 20, 45141 Essen Germany ID n°: 0044	<sup>2)</sup> TÜV CYPRUS Papaflessa 2, 2235 Latsia, Nicosia Cyprus ID n°: 2261
<b>EC- test certificate:</b>	<sup>1)</sup> 44 205 16019910	<sup>2)</sup> TÜV CY 22 ATEX 0206673 X
<b>Person authorised for the compilation of the technical documentation:</b>	Oliver Wacker Möddinghofe 30 42279 Wuppertal	
<b>Place and date of issue:</b>	Wuppertal, November 22, 2022	
EX-SLC-SLG440-A-EN		
	Authorised signature <b>Philip Schmersal</b> Managing Director	



The currently valid declaration of conformity can be downloaded from the internet at [products.schmersal.com](http://products.schmersal.com).

