

## SPACER BNS 36 SPACER



- to mount the magnetic safety sensor and actuator on ferromagnetic material

Schmersal Ltd., Sparrowhawk Close, WR14 1GL Malvern

The details and data referred to have been carefully checked. Images may diverge from original. Further technical data can be found in the manual. Technical amendments and errors possible.

Generated on: 30/11/2024, 12:00