



## PSC1-A-99-SD-MEMORY-CARD

- The SD memory card is used for the optional backup of the user program
- Can be used with all PSC1 control systems with the -MC, -FB1 and -FB2 option

Schmersal, Inc., 115 E Stevens Ave, Suite 208, Valhalla, NY 10595

The details and data referred to have been carefully checked. Images may diverge from original. Further technical data can be found in the manual. Technical amendments and errors possible.

Generated on: 7/6/2025, 4:08 AM