


Commissioning sheet

Classic mode
1.12A

Advanced display mode




Notes:
 underlined data can be selected

Commissioning sheet

classic mode



advanced display mode



Notes:
 underlined data can be selected
 items in italic are not always available

Basic Operation


The device starts in the traditional mode. You can switch between the two modes with **ESC** or **OK**. In the advanced mode the cursor is moved by both arrow buttons. Pushing **OK** puts you to the superior menu (in the drawing one step to the right side). **ESC** puts you back to the previous menu. To edit data you first mark them with the cursor and then select them with **OK**, change them with the arrow buttons and finally apply them with **OK**. Pushing **ESC** cancels the editing.

Commissioning sheet

classic mode



advanced display mode




Basic Operation

The device starts in the traditional mode. You can switch between the two modes with **ESC** or **OK**. In the advanced mode the cursor is moved by both arrow buttons. Pushing **OK** puts you to the superior menue (in the drawing one step to the right side). **ESC** puts you back to the previous menue. To edit data you first mark them with the cursor and then select them with **OK**, change them with the arrow buttons and finally apply them with **OK**. Pushing **ESC** cancels the editing.


Commissioning sheet

Classic mode




Advanced display mode


Notes:
underlined data can be selected

u003Cp></p>


Commissioning sheet



Advanced display mode



Notes:
underlined data can be selected
items in italic are not always available


Basic Operation

The device starts in the traditional mode. You can switch between the two modes with ESC or OK. In the advanced mode the cursor is moved by both arrow buttons. Pushing OK puts you to the superior menue (in the drawing one step to the right side). ESC puts you back to the previous menue. To edit data you first mark them with the cursor and then select them with OK, change them with the arrow buttons and finally apply them with OK. Pushing ESC cancels the editing.

Commissioning sheet



Advanced display mode



Notes:
 underlined data can be selected
 items in italic are not always available

Basic Operation

The device starts in the traditional mode. You can switch between the two modes with ESC or OK. In the advanced mode the cursor is moved by both arrow buttons. Pushing OK puts you to the superior menue (in the drawing one step to the right side). ESC puts you back to the previous menue. To edit data you first mark them with the cursor and then select them with OK, change them with the arrow buttons and finally apply them with OK. Pushing ESC cancels the editing.